ଭୁବନାନନ୍ଦ ଓଡ଼ିଶା ଯାନ୍ତ୍ରିକ ବିଦ୍ୟାଳୟ, କଟକ
BHUBANANANDA ORISSA SCHOOL OF ENGINEERING, CUTTACK
Government of Odisha

LECTURE NOTES ON

OPTO-ELECTRONICS (TH-4A)

5TH SEMESTER (E&TC)

PREPARED BY: PRADEEP KUMAR DHAL SAMANT
LECTURE STAGE II
E &TC DEPT
BOSE, CUTTACK

SYLLABUS

Unit	Topic/Sub Topic	Allotted Time (Hours)
I	**Semiconductors** 1.1 Introduction to semiconductors 1.2 Doping 1.3 Alloy Semiconductors 1.4 Electron-hole pair formation and recombination 1.5 Energy bands in solids	**5**
II	**Optical Processes in Semiconductors** 2.1 Absorption in semiconductors 2.1.1 Indirect intrinsic transitions 2.1.2 Exciton absorption 2.2 Donor acceptor and impurity band absorption 2.3 Effect of electric field on absorption 2.4 Radiation in Semiconductors 2.4.1 Relation between absorption and emission spectra 2.4.2 Near band gap radioactive transitions	**7**
III	**Optoelectronic detectors** 3.1 Photoconductors 3.2 Junction Photodiodes 3.3 PIN Photodiodes 3.4 Heterojunction diodes 3.5 Avalanche Photodiodes 3.6 Phototransistors 3.7 Modulated barrier Photodiode 3.8 Metal semiconductor, metal photodiode	**8**
IV	**Photovoltaic devices** 4.1 Solar energy spectrum 4.2 Device principles 4.3 I - V characteristics 4.4 Equivalent circuit 4.5 Materials, devices and efficiencies	**5**
V	**Light emitting diode** 5.1 Electroluminescent process 5.2 Choice of LED materials 5.3 Device configuration and efficiency 5.4 Light output from LED, LED structure 5.5 Heterojunction LED 5.6 Surface emitting LED 5.7 Device performance characteristics 5.8 Frequency response and modulation bandwidth	**7**
VI	**Laser diode** 6.1 Junction laser operating principles 6.2 Threshold current 6.3 Heterojunction lasers 6.4 Distributed feedback lasers 6.5 Cleaved coupled cavity laser 6.6 Quantum well lasers 6.7 Modulation of lasers - rate equations	**8**

	6.8 Steady state solution 6.9 Transient phenomena and frequency response	
VII	**Optical fiber** 7.1 Introduction to optical fiber 7.2 Structure of optical fiber 7.3 Propagation of light through a numerical aperture 7.4 Pulse broadening 7.5 Advantages and disadvantages of fiber optics	**5**

Chapter – 1: Semiconductors

1.1 Introduction to Semiconductors

Introduction

A semiconductor is a material whose electrical conductivity lies between that of a conductor (such as copper and aluminium) and an insulator (such as glass and rubber). Unlike conductors, which allow electric current to flow freely, and insulators, which almost completely block the flow of current, semiconductors conduct electricity only under certain conditions. Their conductivity can be controlled by changing temperature, light intensity, voltage, or by adding small amounts of impurities. This unique property makes semiconductors the foundation of modern electronic devices.

The most commonly used semiconductor materials are silicon (Si) and germanium (Ge). Among these, silicon is the most widely used because it is abundant, inexpensive, has excellent thermal stability, and forms a protective layer of silicon dioxide (SiO_2), which is very useful in manufacturing electronic circuits.

Atomic Structure of Semiconductors


Semiconductor atoms have four valence electrons in their outermost shell. These electrons form **covalent bonds** with neighbouring atoms, creating a stable crystal structure.

- At **absolute zero temperature (0 K)**, all valence electrons are tightly bound in covalent bonds, so no free electrons are available for conduction. Therefore, a semiconductor behaves like an insulator.
- At **room temperature**, some covalent bonds break due to thermal energy. This releases free electrons into the conduction band and leaves behind vacancies called **holes** in the valence band. Both electrons and holes act as charge carriers and contribute to electric current.

Energy Band Theory

The electrical behaviour of semiconductors is explained by energy band theory. There are three important energy regions:

1. **Valence Band (VB):** Contains electrons involved in covalent bonding.
2. **Conduction Band (CB):** Contains free electrons responsible for electrical conduction.
3. **Forbidden Energy Gap (Band Gap):** The energy difference between the valence band and conduction band.



In semiconductors, the band gap is small enough that electrons can move to the conduction band with a small amount of energy.

Typical band gap values are:

- **Silicon (Si):** 1.12 eV
- **Germanium (Ge):** 0.72 eV

Charge Carriers: Current in a semiconductor is carried by two types of charge carriers:

1. Electrons

- Negatively charged particles.
- Move through the conduction band.
- Responsible for most of the current in n-type semiconductors.

2. Holes

- Positively charged vacancies created when electrons leave covalent bonds.
- Move through the valence band as neighbouring electrons fill the vacancies.
- Responsible for most of the current in p-type semiconductors.

Thus, current in semiconductors is due to the movement of both electrons and holes.

Types of Semiconductors

1. Intrinsic Semiconductor

An intrinsic semiconductor is a pure semiconductor without any added impurities.

Characteristics:

- Equal number of electrons and holes.
- Low electrical conductivity.
- Conductivity increases with temperature.
- Examples: Pure silicon and pure germanium.

2. Extrinsic Semiconductor

An extrinsic semiconductor is formed by adding controlled impurities to increase conductivity. This process is called **doping**.


There are two types:

a) N-type Semiconductor

- Formed by adding pentavalent impurities such as phosphorus, arsenic, or antimony.
- Provides extra free electrons.
- Electrons are the majority carriers.
- Holes are the minority carriers.

b) P-type Semiconductor

- Formed by adding trivalent impurities such as boron, aluminium, gallium, or indium.
- Creates holes in the crystal.
- Holes are the majority carriers.
- Electrons are the minority carriers.



Applications of Semiconductors

Semiconductors are used in almost every electronic system, including:

- Diodes for rectification.
- Transistors for switching and amplification.
- Integrated Circuits (ICs) used in computers and smartphones.
- Solar cells for converting sunlight into electricity.
- LEDs for lighting and displays.
- Photodiodes and optical sensors.
- Microprocessors and memory chips.
- Communication systems.
- Consumer electronics.
- Medical and industrial equipment.

Comparison of Conductors, Semiconductors, and Insulators

Property	**Conductors**	**Semiconductors**	**Insulators**
Conductivity	Very high	Moderate	Very low
Examples	Copper, Silver	Silicon, Germanium	Glass, Rubber
Free electrons	Large number	Few	Almost none
Band gap	0 eV	Small (≈0.7–1.1 eV)	Large (>3 eV)
Temperature effect	Resistance increases	Conductivity increases	Almost no conduction

1.2 Doping

Doping is the process of adding a very small and controlled amount of impurity atoms to a pure (intrinsic) semiconductor, such as silicon (Si) or germanium (Ge), to increase its electrical conductivity. Pure semiconductors have very few free charge carriers at room temperature, so their conductivity is low. By introducing impurities, the number of free electrons or holes increases significantly, making the semiconductor more suitable for electronic applications. The amount of impurity added is extremely small—typically one impurity atom for every million to hundred million semiconductor atoms.

Need for Doping

- Increase the electrical conductivity of the semiconductor.
- Increase the number of free charge carriers (electrons or holes).
- Control the electrical properties of the material.
- Produce **n-type** and **p-type** semiconductors.
- Enable the fabrication of electronic devices such as diodes, transistors, LEDs, ICs, and solar cells.

Principle of Doping

Silicon and germanium atoms have four valence electrons and form four covalent bonds with neighbouring atoms.

When impurity atoms are added:

- **Pentavalent impurities** (having five valence electrons) donate one extra electron, increasing the number of free electrons.

- **Trivalent impurities** (having three valence electrons) create a deficiency of one electron, producing a hole.

Thus, doping increases the number of charge carriers and improves conductivity.

Types of Doping

1. N-type Doping (Donor Doping)

N-type doping is obtained by adding pentavalent impurity atoms to a pure semiconductor.

Examples of pentavalent impurities: Phosphorus (P), Arsenic (As), Antimony (Sb).

Each impurity atom has five valence electrons. Four electrons form covalent bonds with neighbouring silicon atoms, while the fifth electron remains loosely bound and becomes a free electron. Hence, current mainly flows due to the movement of electrons.

2. P-type Doping (Acceptor Doping)

P-type doping is obtained by adding trivalent impurity atoms to a pure semiconductor.

Examples of trivalent impurities: Boron (B), Aluminium (Al), Gallium (Ga), Indium (In).

Each impurity atom has three valence electrons, so it can form only three covalent bonds with neighbouring silicon atoms. One bond remains incomplete, creating a hole. Thus, electrical conduction mainly occurs due to the movement of holes.


Comparison Between N-type and P-type Semiconductors

Property	**N-type Semiconductor**	**P-type Semiconductor**
Doped with	Pentavalent impurity	Trivalent impurity
Examples	Phosphorus, Arsenic, Antimony	Boron, Aluminium, Gallium
Majority carriers	Electrons	Holes
Minority carriers	Holes	Electrons
Type of impurity	Donor impurity	Acceptor impurity
Conductivity due to	Free electrons	Holes

1.3 Alloy Semiconductors

Alloy semiconductors are semiconductor materials formed by combining two or more semiconductor elements in suitable proportions to obtain improved electrical and optical properties. Unlike pure semiconductors such as silicon (Si) and germanium (Ge), alloy semiconductors have properties that can be adjusted by changing the composition of the materials.

Alloy semiconductors are widely used in high-speed communication systems, LEDs, laser diodes, solar cells, and microwave devices because they offer better performance than single-element semiconductors for many applications.



Need for Alloy Semiconductors

Pure semiconductors cannot always satisfy the requirements of modern high-speed and optical devices. Alloy semiconductors are developed to:

- Obtain a desired energy band gap.
- Improve electrical conductivity.
- Increase electron mobility, thus used for high speed operation.
- Improve optical efficiency.
- Enhance high-frequency performance.
- Reduce power consumption.
- Improve device reliability.

Examples of Alloy Semiconductors

1. Silicon-Germanium (SiGe)

- Formed by combining silicon and germanium.
- Used in high-speed integrated circuits and communication devices.
- Offers higher carrier mobility than pure silicon.

2. Aluminium Gallium Arsenide (AlGaAs)

- Formed from aluminium arsenide and gallium arsenide.
- Used in LEDs and laser diodes.
- Provides excellent optical properties.

3. Indium Gallium Arsenide (InGaAs)

- Used in optical communication systems.
- Suitable for infrared detectors and high-speed photodetectors.

4. Gallium Indium Phosphide (GaInP)

- Used in high-efficiency solar cells.
- Also used in LEDs and laser devices.

Applications of Alloy Semiconductors

- High-speed transistors.
- Integrated Circuits (ICs).
- LEDs (Light Emitting Diodes).
- Laser diodes.
- Optical fiber communication systems.
- Solar cells.
- Photodetectors.
- Microwave communication devices.
- Satellite communication systems.
- Mobile and wireless communication equipment.

1.4 Electron–Hole Pair Formation and Recombination

The electrical conductivity of a semiconductor depends on the presence of free electrons and holes, which are known as charge carriers. In a pure semiconductor such as silicon (Si) or germanium (Ge), electrons are normally held in place by covalent bonds. At room temperature or when energy is supplied in the form of heat or light, some electrons gain enough energy to break these covalent bonds. As a result, free electrons and holes are created. This process is called **electron–hole pair formation**. When a free electron later fills a hole, both disappear, and this

process is called **recombination**. These two processes continuously occur in semiconductors and determine their electrical behaviour.

Electron–Hole Pair Formation

Electron–hole pair formation is the process in which a valence electron gains sufficient energy to break its covalent bond and move into the conduction band, leaving behind a hole in the valence band. The free electron and the hole are created together and are therefore called an **electron–hole pair (EHP)**.

Characteristics of Electron–Hole Pair Formation

- Electrons and holes are generated in equal numbers.
- Both electrons and holes act as charge carriers.
- The conductivity of the semiconductor increases due to the increase in charge carriers.
- The number of electron–hole pairs increases with temperature.
- Light energy can also generate electron–hole pairs in photoconductive devices.

Carrier Lifetime (τ): It is the average time between the generation of an excess carrier and its recombination. The excess carrier concentration decays exponentially with time: $\Delta n(t)=\Delta n(0)e^{-t/\tau}$ where:

- $\Delta n(t)$ = Excess carrier concentration at time t
- $\Delta n(0)$ = Initial excess carrier concentration
- τ = Carrier lifetime (in seconds)

Electron–Hole Recombination

Recombination is the process in which a free electron loses energy and falls into a hole, thereby eliminating both the electron and the hole. This process reduces the number of free charge carriers in the semiconductor.

Characteristics of Recombination Process

1. A free electron moves randomly through the conduction band.
2. It eventually encounters a hole in the valence band.
3. The electron loses its excess energy and fills the hole.
4. The free electron disappears, and the hole is also removed.
5. The released energy may appear as **heat** or, in some materials, as **light**.
6. It decreases the electrical conductivity of the semiconductor.
7. It helps to maintain equilibrium in intrinsic semiconductors.

Thus, both charge carriers are eliminated during recombination.

Generation and Recombination Equilibrium

In a semiconductor at a constant temperature:

- New electron–hole pairs are continuously generated.
- Existing electrons and holes continuously recombine.

After some time, an **equilibrium** is reached where:

Rate of electron–hole pair generation = Rate of recombination

At this condition, the average number of free electrons and holes remains constant.

Importance of Electron–Hole Pair Formation and Recombination

- Determines the electrical conductivity of semiconductors.

- Essential for the operation of diodes, transistors, and integrated circuits.
- Plays a major role in solar cells, where sunlight generates electron–hole pairs to produce electricity.
- Forms the working principle of photodiodes and phototransistors.
- Responsible for light emission in LEDs during electron–hole recombination.
- Important in semiconductor lasers and optical communication systems.

Difference Between Electron–Hole Pair Formation and Recombination

Electron–Hole Pair Formation	**Recombination**
Produces free electrons and holes	Eliminates free electrons and holes
Increases conductivity	Decreases conductivity
Requires external energy (heat or light)	Releases energy as heat or light
Charge carriers increase	Charge carriers decrease
Occurs by breaking covalent bonds	Occurs when an electron fills a hole

1.5 Energy Bands in Solids

The Energy Band Theory explains the electrical behaviour of solids such as conductors, semiconductors, and insulators. In an isolated atom, electrons occupy discrete energy levels. However, when a large number of atoms come together to form a solid, these energy levels split into many closely spaced levels, forming energy bands. The movement of electrons between these energy bands determines whether a material behaves as a conductor, semiconductor, or insulator.

An energy band is a range of allowed energy levels occupied by electrons in a solid. The two important energy bands are:

1. Valence Band (VB)

- The valence band is the highest energy band that contains electrons involved in chemical bonding.
- Electrons in this band are tightly bound to the atoms.
- They normally do not contribute to electrical conduction.
- At low temperatures, the valence band is almost completely filled with electrons.

2. Conduction Band (CB)

- The conduction band lies above the valence band.
- Electrons present in this band are free to move throughout the material.
- These free electrons are responsible for electrical conduction.
- When electrons gain sufficient energy, they move from the valence band to the conduction band.


3. Forbidden Energy Gap (Band Gap)

The forbidden energy gap is the energy difference between the valence band and the conduction band.

- It is represented by **Eg**.
- No electrons can normally exist within this gap.
- Electrons must gain energy equal to or greater than the band gap to move into the conduction band.

The size of the band gap determines the electrical conductivity of a material.

Energy Band Diagram



Learn Electronics with me

Energy Bands in Different Materials

1. Conductors

- The valence band and conduction band overlap.
- There is no forbidden energy gap.
- Electrons move freely from one band to another.
- Therefore, conductors have very high electrical conductivity.

Examples: Copper, Silver, Aluminium etc.

2. Semiconductors

- A small forbidden energy gap (nearly 1 ev) exists between the valence band and conduction band.
- At room temperature, some electrons gain enough thermal energy to cross the band gap.
- Both electrons and holes participate in electrical conduction.

Examples: Silicon, Germanium etc.

Band Gap Values: Silicon (Si): 1.12 eV, **Germanium (Ge):** 0.72 eV

3. Insulators

- The forbidden energy gap is very large (more than 15 ev).
- Electrons cannot easily move to the conduction band.
- Therefore, electrical conduction is almost impossible under normal conditions.

Examples: Glass, Rubber, Plastic, Mica etc.

Comparison of Conductors, Semiconductors, and Insulators


Property	**Conductors**	**Semiconductors**	**Insulators**
Band Gap	0 eV (overlap)	Small (0.7–1.2 eV)	Large (>3 eV)
Conductivity	Very high	Moderate	Very low
Free Electrons	Large number	Moderate	Almost none
Temperature Effect	Resistance increases	Conductivity increases	Almost no effect
Examples	Copper, Silver	Silicon, Germanium	Glass, Rubber

Chapter – 2: Optical Processes in Semiconductors

2.1 Absorption in Semiconductors

Absorption in semiconductors is the process by which a semiconductor material absorbs the energy of incident light (photons). When light falls on a semiconductor, photons with sufficient energy transfer their energy to the electrons in the valence band. These electrons gain energy and move to the conduction band, leaving behind holes in the valence band. This process creates **electron–hole pairs**, which increase the electrical conductivity of the semiconductor.

Optical absorption is one of the most important optical processes in semiconductors because it forms the basis of devices such as photodiodes, solar cells, phototransistors, optical sensors, and CCD image sensors.



Principle of Absorption

The absorption of light depends on the energy of the incident photon and the band gap energy (Eg) of the semiconductor.

- If the photon energy (hν) is greater than or equal to the band gap energy (Eg), the photon is absorbed.
- The absorbed energy excites an electron from the valence band to the conduction band.
- A hole is left behind in the valence band.
- Thus, an electron–hole pair is generated. The generated electron–hole pair contributes to electrical conduction.

If the photon energy is less than the band gap energy, the photon passes through the semiconductor without being absorbed.

Mathematically, **Photon Energy (hν) ≥ Band Gap Energy (Eg)**

where:

- **h** = Planck's constant
- **ν** = Frequency of incident light
- **Eg** = Band gap energy

Types of Absorption

1. Intrinsic Absorption

- Occurs in pure (intrinsic) semiconductors.
- Electrons move directly from the valence band to the conduction band.
- Requires photon energy greater than or equal to the band gap.

2. Extrinsic Absorption

- Occurs in doped semiconductors.
- Impurity atoms introduce additional energy levels inside the band gap.
- Electrons require less energy to move into the conduction band.
- Common in infrared detectors.

Factors Affecting Absorption

1. Band Gap Energy

- Smaller band gap → Higher absorption for lower-energy photons.
- Larger band gap → Only high-energy photons are absorbed.

2. Wavelength of Light

- Shorter wavelengths have higher photon energy and are more easily absorbed.
- Longer wavelengths may not have sufficient energy.

3. Material Used

- Different semiconductors have different absorption characteristics.
- Silicon, germanium, and gallium arsenide absorb different wavelength ranges.

4. Temperature

- Increasing temperature slightly reduces the band gap.
- This allows absorption of lower-energy photons.

5. Thickness of Semiconductor

- Thicker materials absorb more light than thinner materials.

Absorption Coefficient

The absorption coefficient (α) indicates how strongly a semiconductor absorbs light.

- High absorption coefficient → Light is absorbed quickly.
- Low absorption coefficient → Light penetrates deeper before being absorbed.

The absorption coefficient depends on wavelength, material, temperature and band gap.

Importance of Absorption

Absorption is essential because it:

- Produces electron–hole pairs.
- Converts light energy into electrical energy.
- Forms the basis of photo detection.
- Enables photovoltaic energy conversion.
- Supports optical communication systems.

2.1.1 Indirect Intrinsic Transitions

An indirect intrinsic transition is an optical absorption process that occurs in indirect band gap semiconductors, such as silicon (Si) and germanium (Ge). In this process, an electron moves from the valence band to the conduction band by absorbing a photon. However, because the minimum of the conduction band and the maximum of the valence band occur at different momentum values, the electron cannot make the transition by absorbing a photon alone. A phonon (a quantum of lattice vibration) is also required to conserve momentum.

Indirect intrinsic transitions are called intrinsic because they occur in pure (undoped) semiconductors.

Working Principle


The process takes place as follows:

1. Light falls on the semiconductor.
2. The semiconductor absorbs a photon.
3. The electron gains energy but still requires a change in momentum. The photon provides the required energy.

4. A phonon is absorbed or emitted to provide the required momentum. The phonon provides the required momentum.
5. The electron moves from the valence band to the conduction band.
6. A hole is left in the valence band, forming an electron–hole pair.

Examples: Indirect intrinsic transitions occur in **Silicon (Si)** and **Germanium (Ge)**.
These materials are widely used in electronic devices because of their excellent electrical properties, although they are less efficient for light emission.

Energy Band Representation



Advantages

- Enables optical absorption in indirect band gap semiconductors.
- Generates electron–hole pairs for electrical conduction.
- Essential for the operation of silicon-based photodetectors and solar cells.
- Widely used in semiconductor electronics.

Applications

Indirect intrinsic transitions are important in:

- Silicon solar cells.
- Silicon photodiodes.
- Optical detectors.
- Integrated circuits.
- Semiconductor sensors.
- Electronic devices based on silicon and germanium.


2.1.2 Exciton Absorption

When light falls on a semiconductor, the energy of the incoming photons can excite electrons from the valence band to the conduction band. Normally, the excited electron and the hole left behind move independently. However, in some cases, the electron and hole remain attracted to each other by the Coulomb (electrostatic) force and form a bound state called an exciton. **An exciton is a neutral quasiparticle consisting of one electron in the conduction band and one hole in the valence band**. The absorption of light that leads to the formation of an exciton is known as exciton absorption.

Exciton absorption is the optical absorption process in which a semiconductor absorbs a photon and creates an exciton instead of producing completely free charge carriers. This

absorption occurs at energy slightly lower than the semiconductor band-gap energy because a small amount of energy (called the binding energy) keeps the electron and hole bound together.

Energy Band Diagram



Characteristics of Exciton Absorption

- Occurs near the band edge.
- Produces sharp absorption peaks.
- More visible at low temperatures.
- Excitons are electrically neutral.
- They transport energy but not electric charge.
- Highly sensitive to crystal quality.

Advantages

- Enhances light absorption near the band edge.
- Improves the efficiency of LEDs and laser diodes.
- Useful in designing high-performance photodetectors.

Applications

- LED technology
- Laser diodes
- Solar cells
- Optical sensors
- Photodetectors
- Semiconductor spectroscopy
- Optoelectronic devices


2.2 Donor, Acceptor and Impurity Band Absorption

Optical absorption in semiconductors is not limited to transitions between the valence band (VB) and conduction band (CB). When impurities (dopants) are added to a semiconductor, they create energy levels inside the forbidden energy gap (band gap). Light can then be absorbed by causing electrons to move between these impurity levels and the energy bands. This process is called impurity absorption.

1. Donor Absorption

Donor absorption is the absorption of light that excites an electron from the donor energy level to the conduction band. A donor impurity (such as phosphorus or arsenic in silicon) introduces an energy level slightly below the conduction band. At low temperatures, electrons remain in the donor level. When a photon with suitable energy is absorbed, the electron gains energy and moves into the conduction band.

Energy Band Diagram




Characteristics

- Occurs mainly in n-type semiconductors.
- Requires small photon energy because the donor level is close to the conduction band.
- Increases electrical conductivity.

2. Acceptor Absorption

Acceptor absorption is the absorption of light that excites an electron from the valence band to the acceptor energy level. An acceptor impurity (such as boron in silicon) creates an energy level slightly above the valence band. When light is absorbed, an electron moves from the valence band to the acceptor level. This leaves behind a free hole in the valence band.

Energy Band Diagram




Characteristics

- Occurs mainly in p-type semiconductors.
- Requires low photon energy.
- Increases hole concentration.

3. Impurity Band Absorption

When the concentration of donor or acceptor atoms becomes very high, the individual impurity levels overlap and form a continuous impurity band inside the band gap. Optical absorption involving this impurity band is called impurity band absorption. At low impurity concentration, donor and acceptor atoms produce isolated energy levels. At high impurity concentration, these levels merge into an impurity band. Electrons can move from the impurity band to the conduction band and from the valence band to the impurity band.

Energy Band Diagram



Characteristics

- Found in heavily doped semiconductors.
- Requires lower photon energy than band-to-band absorption.
- Increases optical absorption.

Applications

- Infrared photodetectors
- Optical sensors
- Semiconductor lasers
- Solar cells
- Electronic and optoelectronic devices

Advantages

- Enables absorption of low-energy photons.
- Improves the sensitivity of semiconductor devices.
- Useful in infrared detection.
- Enhances the performance of photodetectors and solar cells.

Remember:

Donor → Donates electron → Electron moves to the Conduction Band (CB).
Acceptor → Accepts electron → Electron moves from the Valence Band (VB).
Heavy doping → Impurity levels merge → Impurity Band forms.

2.3 Effect of Electric Field on Absorption (Electro-Absorption)


The effect of an electric field on absorption refers to the change in the optical absorption properties of a semiconductor when an external electric field is applied. The electric field modifies the energy levels of electrons and holes, causing a change in the absorption coefficient and shifting the absorption edge. This phenomenon is called electro-absorption.

Working Principle

A semiconductor is placed in an external electric field. The electric field distorts the energy bands. Electrons require slightly less energy to move to the conduction band. Light with lower energy can now be absorbed. As a result, the optical absorption coefficient changes.

Energy Band Diagram

(a) Without Electric Field **(b) With Electric Field**



The tilted bands indicate the influence of the applied electric field.

Effects of Electric Field

- Changes the absorption coefficient.
- Shifts the absorption edge.
- Reduces the effective band gap.
- Increases carrier generation.
- Improves sensitivity of photodetectors.
- Enables fast optical switching.

Applications: It is used in electro-optic modulators, optical communication systems, photodetectors, laser diodes, optical switches, high-speed communication systems and optical sensors

Advantages

- Fast response time.
- Low power consumption.
- High-speed modulation of light.
- Improves performance of optoelectronic devices.
- Enables compact integrated optical circuits.


2.4 Radiation in Semiconductors

Radiation in semiconductors is the process in which energy is emitted from a semiconductor in the form of electromagnetic waves (photons/light) when excited electrons return from the conduction band (CB) to the valence band (VB).

When a semiconductor absorbs electrical or optical energy, electrons are excited from the valence band to the conduction band, leaving holes in the valence band. As these electrons return to lower energy states, they release energy and recombines with holes. This released energy may be emitted as light (radiative recombination) or as heat (non-radiative recombination).

Radiation in semiconductors is the basic operating principle of LEDs, laser diodes, and semiconductor light sources.

Energy Band Diagram



Types of Radiation in Semiconductors

1. Radiative Recombination

Radiative recombination is the process in which an electron recombines with a hole and releases its energy in the form of a photon (light). **Examples -** Gallium Arsenide (GaAs), Gallium Nitride (GaN), Indium Phosphide (InP)

Characteristics

- Produces visible or infrared light.
- Highly efficient in direct band-gap semiconductors.
- Used in LEDs and laser diodes.

2. Non-Radiative Recombination

In non-radiative recombination, the electron-hole pair recombines without emitting light. The energy is released as heat or transferred to lattice vibrations (phonons). **Example -** Silicon (Si), Germanium (Ge).

Characteristics

- No light emission.
- Common in indirect band-gap semiconductors.
- Reduces the efficiency of light-emitting devices.

Direct and Indirect Band-Gap Semiconductors

Direct Band-Gap Semiconductor: Electron recombines directly with the hole and emits a photon efficiently. It is a good light emitter. It is used in LEDs and lasers. **Examples:** GaAs, GaN, InP

Indirect Band-Gap Semiconductor: Recombination requires the participation of a phonon. Most energy is released as heat. It is a poor light emitter. **Examples:** Silicon (Si), Germanium (Ge)

Factors Affecting Radiation

- Band-gap energy
- Semiconductor material
- Temperature
- Impurity concentration
- Carrier concentration
- Crystal quality

2.4.1 Relation between Absorption and Emission Spectra

In semiconductors, absorption and emission are two opposite optical processes. Absorption occurs when a semiconductor absorbs photons and electrons move from the valence band (VB) to the conduction band (CB). Emission occurs when excited electrons return from the conduction band to the valence band and release energy as photons. The absorption spectrum is a graph showing how much light of different wavelengths or frequencies is absorbed by a semiconductor. The emission spectrum is a graph showing the light emitted by a semiconductor when excited electrons return to lower energy levels.

Relationship


1. Same Energy Levels: Both involve transitions between conduction band and valence band.

2. Opposite Processes: Absorption: Photon energy is absorbed. Emission: Photon energy is released.

3. Band-Gap Dependence: The photon energy in both processes is approximately equal to the band-gap energy: Photon Energy (E) = Band Gap (Eg) = $h\nu = hc/\lambda$

4. Similar Spectral Position: The emission peak usually appears close to the absorption edge. In practice, the emission wavelength is often slightly longer due to energy losses (Stokes shift).

Energy Band Diagram



Factors Affecting Both Spectra

- Band-gap energy
- Temperature
- Impurity concentration
- Crystal quality
- External electric field
- Semiconductor material

2.4.2 Near Band-Gap Radiative Transitions


Near band-gap radiative transitions are optical transitions in which an electron recombines with a hole near the band-gap energy (Eg) of a semiconductor and emits a photon (light). These transitions are called radiative because the recombination releases energy in the form of electromagnetic radiation (photons). They are responsible for light emission in LEDs, laser diodes, and other optoelectronic devices.

The energy of the emitted photon or photon energy is approximately: $E_{photon} \approx Eg$
where: E_g = Band-gap energy

Working Principle

External energy (electrical or optical) excites electrons from the valence band to the conduction band. Holes are created in the valence band. The excited electrons lose excess energy and move near the bottom of the conduction band. Electrons recombine with holes near the band edge. The released energy is emitted as a photon.

Energy Band Diagram



Characteristics

- Photon energy is nearly equal to the band-gap energy.
- Produces visible, infrared, or ultraviolet light depending on the semiconductor.
- Highly efficient in direct band-gap semiconductors.
- Used in LEDs, laser diodes, optical communication systems, semiconductor lasers, and optical sensors.

Chapter 3: Optoelectronic Detectors


3.1 Photoconductors


A photoconductor is an optoelectronic device whose electrical conductivity increases when light falls on it. It works on the principle of photoconductivity, where incident light generates electron-hole pairs, increasing the number of charge carriers and reducing the electrical resistance of the semiconductor. Photoconductors are widely used for detecting light in automatic lighting systems, optical sensors, burglar alarms, cameras, and industrial control systems.

Working Principle

A voltage is applied across the photoconductor. In darkness, very few free charge carriers are available, so only a small current flows because of high resistance. When light falls on the semiconductor, photons generate electron-hole pairs. The conductivity increases due to more free charge carriers. A larger current flows through the circuit. The output current is proportional to the intensity of the incident light.

Energy Band Diagram





Construction

A photoconductor consists of a semiconductor material (such as Cadmium Sulphide (CdS) or Cadmium Selenide (CdSe), Lead Sulphide (PbS), Lead Selenide (PbSe), Silicon (Si)), two metal electrodes, an insulating substrate and a transparent cover to allow light to reach the semiconductor.

Advantages

- Simple and inexpensive.
- High sensitivity.
- Easy to manufacture.
- Long operating life.
- Suitable for detecting low levels of light.

Disadvantages

- Slower response than photodiodes.

- Requires an external voltage source.
- Performance changes with temperature.
- Less suitable for high-speed communication.

Applications


- Automatic street lights
- Light meters
- Camera exposure control
- Burglar alarm systems
- Smoke detectors
- Industrial automation
- Optical sensors
- Flame detectors

3.2 Junction Photodiodes

A junction photodiode is a reverse biased P-N junction semiconductor device that detects light by converting incident photons or light energy into electrical current. It works on the internal photoelectric effect.

When light falls on the depletion region of the PN junction, electron-hole pairs are generated. The electric field in the depletion region separates these charge carriers, producing a photocurrent. The photocurrent is directly proportional to the intensity of the incident light.

Energy Band Diagram



Types of Photodiodes

1. PN Junction Photodiode

- Basic photodiode.
- Moderate speed and sensitivity.

2. PIN Photodiode

- Contains an intrinsic (I) layer between P and N regions.
- Higher sensitivity.
- Faster response than PN photodiodes.

3. Avalanche Photodiode (APD)

- Operates at high reverse voltage.
- Provides internal current amplification.
- Very high sensitivity.

Advantages

- High-speed operation.
- Small size.
- Long operating life.
- Low power consumption.
- Reliable and stable performance.
- Good sensitivity.

Disadvantages

- Requires reverse-bias voltage.
- Sensitive to temperature changes.
- Lower output current compared to photoconductors.
- Output current is very small and may require amplification.

Applications

- Optical fiber communication
- Barcode scanners
- Medical equipment
- Optical sensors
- Automatic lighting systems
- Smoke detectors
- Remote control receivers
- Camera light sensors

3.3 PIN Photodiodes


A PIN photodiode is a special type of photodiode that consists of three semiconductor layers: P-type, Intrinsic (I-type), and N-type. It is a reverse-biased semiconductor photodetector which converts incident light into electrical current. Compared to a PN junction photodiode, the PIN photodiode has a wider depletion region, making it more sensitive to light, faster in response, and suitable for high-speed optical communication.

Principle of Operation

A PIN photodiode works on the internal photoelectric effect. The PIN photodiode is connected in reverse biased. The intrinsic layer is a pure, undoped semiconductor placed between the P and N regions. The intrinsic layer increases the width of the depletion region, allowing more photons to be absorbed.

In darkness, only a very small dark current flows. When light with energy greater than or equal to the band-gap energy (Eg) falls on the intrinsic region, Photons are absorbed and electron-hole pairs are generated. The reverse electric field separates the electrons and holes. Electrons move toward the N-region, and holes move toward the P-region. A photocurrent flows through the external circuit. The photocurrent is directly proportional to the intensity of the incident light.

Structure Diagram



Advantages

- Faster than PN photodiodes.
- High sensitivity.
- Suitable for high-frequency signals.
- Low capacitance.
- Wide bandwidth.
- Reliable operation.
- Good linearity.

Disadvantages

- Requires reverse-bias voltage.
- Higher cost than PN photodiodes.
- Small dark current is present.
- Output current may require amplification.

Applications

- Optical fiber communication
- High-speed data transmission
- Laser communication systems
- Medical instruments
- Optical sensors
- Barcode scanners
- Optical receivers
- Industrial automation

3.4 Heterojunction Diodes

A heterojunction diode is a semiconductor diode formed by joining two different semiconductor materials having different band-gap energies and electron affinities. Unlike a homojunction diode, where both sides are made of the same semiconductor (such as silicon-silicon), a heterojunction diode uses different materials (such as Gallium Arsenide (GaAs) and Aluminium Gallium Arsenide (AlGaAs), Indium Phosphide (InP) / Indium Gallium Arsenide (InGaAs), Silicon (Si) / Germanium (Ge)).


Because of their superior electrical and optical properties, heterojunction diodes are widely used in high-speed photodetectors, LEDs, laser diodes, solar cells, and optical communication systems.

Principle of Operation

A heterojunction diode works on the internal photoelectric effect. The diode is usually operated in reverse bias. When light falls on the junction, photons are absorbed and electron-hole pairs are generated near the heterojunction. The built-in electric field separates the charge carriers. The charge carriers move toward opposite terminals and a photocurrent flows through the external circuit. The output current increases with light intensity.

Because the two semiconductor materials have different band gaps, carrier movement is more efficient, leading to improved sensitivity and speed.

Structure Diagram



Advantages

- Higher efficiency than homojunction diodes.
- Faster carrier transport.
- Better light absorption.
- Lower recombination losses.
- High-speed operation.

- High reliability.
- Suitable for optical communication.

Disadvantages

- Complex fabrication process.
- Higher manufacturing cost.
- Requires high-quality crystal growth.
- Different materials must be carefully matched.


Applications

- Optical fiber communication
- High-speed photodetectors
- LEDs
- Laser diodes
- Solar cells
- Optical sensors
- Satellite communication
- Medical optical instruments

3.5 Avalanche Photodiodes (APD)

An Avalanche Photodiode (APD) is a highly sensitive semiconductor photodetector that converts light into electrical current. It operates under high reverse-bias voltage and uses the avalanche multiplication process to amplify the photocurrent internally. An Avalanche Photodiode consists of a P-type semiconductor, Intrinsic (I) or multiplication region and a N-type semiconductor. Compared to a PIN photodiode, an APD provides higher sensitivity because a single photon can generate many charge carriers through impact ionization.

Structure Diagram



Principle of Operation

An APD works on the principles of:

1. Internal Photoelectric Effect
2. Impact Ionization (Avalanche Multiplication)

When light falls on the depletion region, photons generate electron-hole pairs. Due to the high reverse voltage, these charge carriers accelerate rapidly. The fast-moving electrons collide with semiconductor atoms, creating additional electron-hole pairs. This chain reaction is called avalanche multiplication. As a result, a large photocurrent is produced.

Advantages

- Very high sensitivity.
- Internal signal amplification.
- Fast response.
- Excellent performance for weak light detection.
- Suitable for long-distance optical communication.
- High quantum efficiency.

Disadvantages

- Requires a high reverse-bias voltage.
- More expensive than PIN photodiodes.
- Sensitive to temperature changes.
- Generates higher noise due to avalanche multiplication.
- Requires precise bias control.

Applications

- Optical fiber communication
- LiDAR (Light Detection and Ranging)
- Laser range finders
- Medical imaging equipment
- Optical receivers
- Night vision systems
- Scientific instruments
- Satellite communication

3.6 Phototransistors


A phototransistor is a light-sensitive semiconductor device that converts light into an electrical signal. It is similar to a normal bipolar junction transistor (BJT), but instead of using a large base current, it uses incident light to control the collector current. A phototransistor is more sensitive than a photodiode because it provides current amplification.

Principle of Operation

A phototransistor works on the internal photoelectric effect. The phototransistor is connected in reverse bias between the collector and base junction. When photons with energy greater than or equal to the band-gap energy (Eg) fall on the base-collector junction, electron-hole pairs are generated. These carriers produce a small photocurrent, which acts as the base current. The

transistor amplifies this current. A much larger collector current flows through the circuit. Thus, even a small amount of light can produce a large output current.

Structure Diagram



Advantages

- High sensitivity to light.
- Current amplification.
- Simple circuit design.
- Low cost.
- Good output signal.
- Suitable for detecting weak light.

Disadvantages

- Slower response than photodiodes.
- Sensitive to temperature changes.
- Limited high-frequency performance.
- Higher dark current than photodiodes.


Applications

- Automatic street lights
- Smoke detectors
- Object detection systems
- Optical switches
- Barcode readers
- Infrared receivers
- Security systems
- Industrial automation

3.7 Modulated Barrier Photodiode (MBP)

A Modulated Barrier Photodiode (MBP) is a special type of photodetector in which the potential barrier of a semiconductor is controlled (modulated) by incident light. The change in the barrier height causes a change in the output current which is proportional to the light falling on the device. A typical MBP consists of a semiconductor layer, barrier (Schottky or heterojunction) region, ohmic contact, metal contact and a transparent window for light entry.


Structure Diagram



Principle of Operation

The MBP works on the modulation of the barrier potential. When light falls on the semiconductor, photons generate electron-hole pairs. These carriers reduce or modify the barrier height. The lowered barrier allows more charge carriers to cross the junction. As a result, the output current increases. The output current is directly proportional to the intensity of the incident light.

Energy Band Diagram



Advantages

- High photo-detection efficiency.
- Low dark current.
- Fast switching speed.
- High signal-to-noise ratio.
- Better sensitivity than ordinary photodiodes.
- Stable operation.

Disadvantages

- Complex fabrication.
- Higher manufacturing cost.
- Performance depends on material quality.
- Limited commercial availability compared to PIN and APD photodiodes.

Applications

- Optical fiber communication
- Optical sensors
- Scientific instruments
- Imaging systems
- High-speed optical receivers
- Industrial automation
- Laser detection systems


3.8 Metal–Semiconductor–Metal (MSM) Photodiode

A Metal–Semiconductor–Metal (MSM) photodiode is a high-speed photodetector in which two metal electrodes are deposited on the surface of a semiconductor, forming two Schottky (metal–semiconductor) junctions. It converts incident light into electrical current and is known for its high-speed operation.

Unlike a PN or PIN photodiode, the MSM photodiode has two metal contacts separated by a small gap. When light falls on the semiconductor between the electrodes, electron-hole pairs are generated, producing a photocurrent.

Construction

An MSM photodiode consists of two metal electrodes (Schottky contacts), semiconductor substrate (usually Silicon (Si) or Gallium Arsenide (GaAs)), small gap between the electrodes and a transparent surface for light entry.



Principle of Operation

The MSM photodiode works on the internal photoelectric effect. When light with energy greater than or equal to the band-gap energy (Eg) falls on the semiconductor, electron-hole pairs are generated. An applied electric field separates the electrons and holes. The charge carriers move toward opposite metal contacts. A photocurrent flows through the external circuit. The photocurrent is directly proportional to the intensity of the incident light.

Advantages

- Very high-speed operation.
- Low capacitance.
- Simple fabrication process.
- Compact structure.
- High bandwidth.
- Compatible with integrated circuits.

Disadvantages

- Higher dark current than PIN photodiodes.
- Lower quantum efficiency.
- Requires external bias.
- Less sensitive than Avalanche Photodiodes (APDs).

Applications

- Optical fiber communication
- High-speed optical receivers
- Optical switching
- Optical sensors
- High-speed data transmission
- Integrated optoelectronic circuits
- Laser communication systems


Chapter – 4: Photovoltaic Devices

4.1 Solar Energy Spectrum

The solar energy spectrum is the distribution of the Sun's electromagnetic radiation over different wavelengths. It represents the amount of solar energy available at each wavelength, ranging from ultraviolet (UV) rays to visible light and infrared (IR) radiation. This spectrum is the primary source of energy used by photovoltaic (solar cell) devices to generate electricity. Solar energy is one of the most abundant and renewable energy sources available on Earth.

Electromagnetic Spectrum of Solar Radiation

The Sun emits radiation over a broad range of wavelengths.



1. Ultraviolet (UV) Radiation

- Has the shortest wavelength **(100 nm to 400 nm)** and highest photon energy.
- Makes up approximately **7%** of the total solar energy.
- Much of the UV radiation is absorbed by the Earth's ozone layer.
- High-energy UV photons can damage photovoltaic materials over time.

2. Visible Radiation

- Covers wavelengths from **400 nm to 700 nm**.
- Accounts for approximately **43%** of solar energy.
- This is the portion visible to the human eye.
- Most photovoltaic cells absorb visible light very efficiently, making it the most useful part of the solar spectrum.

3. Infrared (IR) Radiation

- Covers wavelengths from **700 nm to about 1 mm**.
- Contributes nearly **50%** of the solar energy reaching Earth.
- Lower-energy infrared photons mainly produce heat.
- Some infrared photons have insufficient energy to generate electron-hole pairs in silicon solar cells.

Interaction of Solar Radiation with the Atmosphere

As sunlight passes through the Earth's atmosphere, several processes occur:

Absorption

Atmospheric gases such as ozone, oxygen, carbon dioxide, and water vapor absorb certain wavelengths of sunlight.

Scattering

Dust particles, water droplets, and air molecules scatter sunlight, reducing its intensity before it reaches the Earth.

Reflection

Clouds and atmospheric particles reflect a portion of the incoming solar radiation back into space. As a result, only about **70–75%** of the Sun's energy reaches the Earth's surface under clear weather conditions.

Importance of Solar Spectrum in Photovoltaic Devices


The solar spectrum plays a crucial role in determining the efficiency of solar cells.

- Solar cells convert light into electricity by absorbing photons.
- Only photons having energy greater than the semiconductor band gap can create electron-hole pairs.
- Photons with energy lower than the band gap pass through the material without generating electricity.
- Excess photon energy above the band gap is converted into heat, reducing efficiency.
- Different semiconductor materials are selected based on how well they match the solar spectrum.
- Silicon is the most commonly used photovoltaic material because its band gap of **1.12 eV** matches a large portion of the visible and near-infrared spectrum. Silicon solar cells convert approximately **15–25%** of incident sunlight into electrical energy in commercial modules.

4.2 Device Principles

The device principle of a photovoltaic device is based on the **photovoltaic effect**, where sunlight is converted directly into electrical energy using a semiconductor p-n junction. When photons are absorbed, electron-hole pairs are generated and separated by the built-in electric field, producing a flow of electric current through an external circuit. Photovoltaic devices are usually made from silicon that generates electricity without any moving parts or external fuel.

Construction of a Photovoltaic Device



Photovoltaic Cell

A typical photovoltaic device consists of the following components:

1. P-type Semiconductor Layer

- Formed by doping silicon with trivalent impurities such as boron.

2. N-type Semiconductor Layer

- Formed by doping silicon with pentavalent impurities such as phosphorus.

3. P-N Junction

- Formed where the P-type and N-type layers meet.
- Creates a depletion region with a built-in electric field.
- Responsible for separating electrons and holes.

4. Front Metal Contact

- Collects electrons generated inside the solar cell.
- Designed as thin metal grid lines to allow maximum sunlight to enter.

5. Back Metal Contact

- Completes the electrical circuit.
- Collects holes and provides external connection.


6. Anti-Reflection Coating

- Reduces reflection losses.
- Increases the amount of sunlight absorbed by the cell.

7. Protective Glass Cover

- Protects the solar cell from dust, moisture, and mechanical damage.
- Allows sunlight to pass with minimal loss.

Working Principle of a Photovoltaic Device



The operation of a photovoltaic device can be explained in the following steps:

Step 1: Absorption of Sunlight

When sunlight falls on the surface of the solar cell, photons enter the semiconductor material. If the photon energy is greater than or equal to the band gap energy, the photons are absorbed.

Step 2: Generation of Electron-Hole Pairs

The absorbed photon transfers its energy to an electron. The electron gains sufficient energy to move from the valence band to the conduction band, leaving behind a hole. Thus, an **electron-hole pair** is generated.

Step 3: Separation of Charge Carriers

The built-in electric field in the depletion region separates the generated carriers.

- Electrons move toward the N-region.
- Holes move toward the P-region.


This separation prevents recombination.

Step 4: Collection of Charge Carriers

The separated electrons and holes are collected by the metal contacts. The front contact collects electrons while the back contact collects holes.

Step 5: Flow of Electric Current

When an external load is connected, electrons flow through the external circuit from the N-side to the P-side. This flow of electrons produces direct current (DC) electricity, which can power electrical devices.



(Symbol of Photovoltaic Cell)

Advantages of Photovoltaic Devices

- Generate clean and renewable energy.
- No fuel is required.
- Environment-friendly and pollution-free.
- Low maintenance.
- Long service life.
- Reliable and durable.
- Suitable for remote and off-grid locations.
- Can be installed on rooftops and open fields.
- Reduce dependence on fossil fuels.

Limitations of Photovoltaic Devices

- High initial installation cost.
- Dependence on sunlight availability.
- Energy storage (batteries) may be required for night-time use.
- Efficiency decreases with increasing temperature.


Applications of Photovoltaic Devices

- Residential rooftop solar systems.
- Commercial and industrial solar power plants.
- Street lighting.
- Solar-powered water pumps.
- Traffic signals.
- Calculators and watches.
- Satellites and spacecraft.
- Remote communication systems.
- Portable electronic devices.
- Rural electrification.

4.3 I–V Characteristics of Photovoltaic Devices

The I–V (Current–Voltage) characteristics of a photovoltaic (PV) device describe the relationship between the output current (I) and the output voltage (V) of a solar cell under a given level of sunlight and temperature. The I–V curve is one of the most important characteristics used to evaluate the performance and efficiency of a solar cell.

The shape of the I–V curve helps to determine important parameters such as **short-circuits current (ISC)**, **open-circuit voltage (VOC)**, **maximum power point (MPP)**, **fill factor (FF)**, and **conversion efficiency (η)**.



Where:

- **ISC** = Short-Circuit Current
- **VOC** = Open-Circuit Voltage
- **MPP** = Maximum Power Point

1. Short-Circuit Current (ISC) - It is the maximum current produced by the solar cell when the output terminals are shorted. It increases with increasing solar radiation.

2. Open-Circuit Voltage (VOC) - It is the maximum voltage produced when no load is connected. It depends on semiconductor material and temperature. It decreases as temperature increases.

3. Maximum Power Point (MPP) – It is the operating point where the product of voltage and current is maximum. Solar cells operate most efficiently at the MPP. At this point,

Maximum Power (Pmax) = Vm × Im

Where,

- Vm = Voltage at maximum power
- Im = Current at maximum power

4. Fill Factor (FF) – It is the ratio of the maximum power delivered by the solar cell to the product of the open-circuit voltage and short-circuit current. FF Indicates the quality of the solar cell.

FF = $(V_m \text{ X } I_m) \ / (V_{oc} \text{ X } I_{sc})$

Where,

- V_m = Voltage at maximum power
- I_m = Current at maximum power
- V_{oc} = Open-circuit voltage
- I_{sc} = Short-circuit current

Higher FF means better performance. Typical value of FF for silicon solar cells is **0.70–0.85**.

5. Conversion Efficiency (η) – It is the percentage of incident solar energy converted into electrical energy. Higher efficiency indicates better energy conversion.

η = P_{out} / P_{in} X 100%

Where,

- $\mathbf{P_{out}}$ = Electrical output power
- $\mathbf{P_{in}}$ = Incident solar power

Effect of Sunlight Intensity on I–V Characteristics

When sunlight intensity increases:

- Short-circuit current increases significantly.
- Maximum power increases.
- Open-circuit voltage increases slightly.
- Overall efficiency improves.

Effect of Temperature on I–V Characteristics

As temperature increases:

- Open-circuit voltage decreases.
- Efficiency decreases.
- Maximum power decreases.
- Short-circuit current increases slightly.

Therefore, solar cells perform better at **lower temperatures**.


Power–Voltage (P–V) Characteristics

The power produced by the solar cell is: P = V X I

The P–V curve rises with voltage, reaches the **Maximum Power Point (MPP)**, and then falls to zero at the open-circuit voltage.

4.4 Equivalent Circuit of a Photovoltaic Device

The equivalent circuit of a photovoltaic (PV) device is an electrical model that represents the behaviour of a solar cell using basic electrical components such as a current source, diode, series resistance (Rs), and shunt resistance (Rsh). This model helps in understanding, analyzing, and predicting the electrical performance of a solar cell under different operating conditions.



1. Photocurrent Source (IL) - The photocurrent source represents the electric current generated when sunlight falls on the solar cell.

2. Diode - The diode represents the p–n junction of the solar cell.

3. Series Resistance (Rs) - Series resistance represents the internal resistance encountered by current flowing through the solar cell. The value of **Rs** should be as low as possible.

4. Shunt Resistance (Rsh) - Shunt resistance represents the leakage current path inside the solar cell. The value of **Rsh** should be as high as possible.

Output Current Equation

The output current of a practical solar cell is given by:

$I = I_l - I_d - I_{sh}$

Where,

- **I** = Output current
- $\mathbf{I_l}$ = Photocurrent generated by sunlight
- $\mathbf{I_d}$ = Diode current
- $\mathbf{I_{sh}}$ = Shunt leakage current

4.5 Materials, Devices and Efficiencies

Different semiconductor materials are used to manufacture various types of solar cells, each having different characteristics, efficiencies, costs, and applications. The efficiency of a photovoltaic device is the measure of how effectively it converts incident solar energy into electrical energy.

An ideal photovoltaic material should have an appropriate band gap, high optical absorption, good electrical conductivity, long carrier lifetime, and high stability under sunlight.

Types of Photovoltaic Materials

1. Crystalline Silicon (c-Si) – It is the most widely used photovoltaic material because of its excellent electrical properties and long-term reliability.

Types: (i) Monocrystalline Silicon (ii) Polycrystalline Silicon

2. Thin-Film Solar Cell Material – It is manufactured by depositing very thin semiconductor layers onto substrates such as glass, metal, or plastic.

Types: (i) Amorphous Silicon (a-Si) (ii) Cadmium Telluride (CdTe)
(iii) Copper Indium Gallium Selenide (CIGS)

3. Gallium Arsenide (GaAs) – Gallium arsenide is a high-performance semiconductor used mainly in satellites and space applications.

4. Perovskite Solar Cells – Perovskite solar cells are an emerging photovoltaic technology that has gained attention because of their rapid improvement in efficiency.

Comparison of Different Photovoltaic Materials

Material	Efficiency	Advantages	Limitations
Monocrystalline Silicon	20–27%	Highest silicon efficiency, long life	Expensive
Polycrystalline Silicon	15–22%	Low cost, reliable	Lower efficiency
Amorphous Silicon	6–12%	Flexible, lightweight	Low efficiency
Cadmium Telluride (CdTe)	16–22%	Low manufacturing cost	Cadmium toxicity concerns
Copper Indium Gallium Selenide (CIGS)	15–23%	Flexible, good low-light performance	Complex manufacturing
Gallium Arsenide (GaAs)	25–35%	Very high efficiency	Very expensive
Perovskite	20–30%	High efficiency, low cost	Stability issues

Types of Photovoltaic Devices

1. Single-Junction Solar Cells

- Made using one semiconductor material.
- Simple structure.
- Lower efficiency than multi-junction cells.
- Widely used in residential solar panels.

2. Multi-Junction Solar Cells

- Consist of multiple semiconductor layers.
- Each layer absorbs different wavelengths of sunlight.
- Higher efficiency.
- Mainly used in satellites and concentrated solar systems.

3. Thin-Film Solar Cells

- Flexible and lightweight.
- Lower manufacturing cost.
- Suitable for portable devices and building-integrated photovoltaics.

4. Concentrated Photovoltaic (CPV) Devices

- Use lenses or mirrors to focus sunlight onto high-efficiency solar cells.
- Produce high power output.
- Require solar tracking systems.

Efficiency of Photovoltaic Devices

The efficiency of a photovoltaic device is the ratio of electrical output power to the incident solar power.

$\eta = Pout / Pin \times 100\%$

Where:

- **η** = Efficiency
- **Pout** = Electrical output power
- **Pin** = Incident solar power

Higher efficiency means more sunlight is converted into electricity.

Factors Affecting Efficiency

1. Semiconductor Material: Materials with suitable band gaps produce higher efficiencies.
2. Sunlight Intensity: Greater solar irradiance generates more electrical power.
3. Temperature: High temperatures reduce the output voltage and overall efficiency.
4. Surface Reflection: Reflection reduces light absorption and decreases efficiency.
5. Recombination of Charge Carriers: Electron-hole recombination before collection lowers efficiency.
6. Internal Resistive Losses: High series resistance and low shunt resistance reduce power output.
7. Dust and Shading: Dust accumulation and partial shading decrease the amount of sunlight reaching the solar cell.

Chapter – 5: Light Emitting Diode (LED)

5.1 Electroluminescent Process

The electroluminescent process is the phenomenon in which a semiconductor material emits light when an electric current passes through it. This process occurs in a Light Emitting Diode (LED) when electrons and holes recombine at the p-n junction, releasing energy in the form of photons (light).

Electroluminescence is the fundamental operating principle of LEDs and is widely used in lighting, display systems, communication, and optoelectronic devices.

Working of the Electroluminescent Process

The electroluminescent process takes place in the following steps:

Step 1: Forward Biasing - A forward voltage is applied across the LED.

- Positive terminal is connected to the P-region.
- Negative terminal is connected to the N-region.

This reduces the width of the depletion region.

Step 2: Injection of Charge Carriers - Electrons from the N-region move toward the junction. Holes from the P-region also move toward the junction.

Step 3: Recombination - Electrons combine with holes near the p-n junction. The electron falls from the conduction band to the valence band.

Step 4: Emission of Light - During recombination, the energy difference between the conduction band and the valence band is released as photons. These photons emerge from the LED as visible or infrared light.

The emitted photon energy is approximately: $\mathbf{E = h\nu = hc / \lambda}$

Where, $\mathbf{h}$ = Planck's constant = 6.626×10^{-34} Joule-sec

$\boldsymbol{\nu}$ = Frequency of light

$\mathbf{c}$ = Speed of light = 3×10^{8} m/sec

$\boldsymbol{\lambda}$ = Wavelength of emitted light

5.2 Choice of LED Materials

The choice of LED materials refers to the selection of suitable semiconductor materials for manufacturing Light Emitting Diodes (LEDs).

LEDs are specially designed using **direct band-gap semiconductor materials** such as Gallium Arsenide (GaAs), Gallium Phosphide (GaP), Gallium Arsenide Phosphide (GaAsP), and Gallium Nitride (GaN). These materials efficiently convert electrical energy into visible or infrared light through the **electroluminescent process**. Different semiconductor materials emit different colors of light. The selection of LED material depends on colour, band-gap energy, emission wavelength, efficiency, operating temperature, cost, reliability and brightness.

Requirements of an Ideal LED Material

A good LED material should have the following properties:

- Direct band-gap semiconductor.
- High light-emission efficiency.
- Suitable band-gap energy for the required wavelength.
- High electrical conductivity.
- Low power consumption.

- High thermal stability.
- Long operating life.
- High reliability.
- Good mechanical strength.
- Easy fabrication and low manufacturing cost.

Common LED Materials and Their Characteristics

Semiconductor Material	Band-Gap Nature	Emitted Light	Characteristics
Gallium Arsenide (GaAs)	Direct	Infrared	High efficiency. Used in Remote controls, optical fiber communication, Infrared sensors.
Gallium Phosphide (GaP)	Direct	Green or Red	Moderate efficiency and good brightness. Used in Indicator lamps, display panels, signal lights.
Gallium Arsenide Phosphide (GaAsP)	Direct	Red, Orange, Yellow	Good efficiency. Used in digital displays, seven-segment displays, indicator LEDs.
Gallium Nitride (GaN)	Direct	Blue, Violet	High brightness and high-temperature operation. Used in white LEDs, blue LEDs, solid-state lighting.
Indium Gallium Nitride (InGaN)	Direct	Blue, Green	Very high efficiency and high brightness. Used in LED televisions, mobile phone displays, general lighting.
Aluminum Gallium Indium Phosphide (AlGaInP)	Direct	Red, Orange, Yellow	High efficiency and very high brightness. Used in traffic signals, automotive lighting, outdoor displays.
Silicon (Si)	Indirect	Not suitable for LEDs	
Germanium (Ge)	Indirect	Not suitable for LEDs	

5.3 Device Configuration and Efficiency

Device configuration refers to the physical structure and arrangement of the different layers and components of a Light Emitting Diode (LED), such as the semiconductor layers, p-n junction, electrical contacts, reflector, and encapsulation. The configuration determines how efficiently electrical energy is converted into light and how effectively the emitted light is extracted from the device.

Basic Device Configuration of an LED: A typical LED consists of the following parts:

1. P-Type Semiconductor Layer

- Doped with trivalent impurities.
- Contains holes as majority charge carriers.
- Forms one side of the p-n junction.

2. N-Type Semiconductor Layer

- Doped with pentavalent impurities.
- Contains electrons as majority charge carriers.
- Forms the other side of the p-n junction.

3. P–N Junction (Active Region)

- Region where electrons and holes recombine.
- Light is generated in this active region.
- Determines the wavelength of emitted light.

4. Metal Contacts

- Provide electrical connection to the LED.
- Front contact allows current injection.
- Back contact completes the electrical circuit.
- Designed to minimize resistance and maximize current flow.

5. Reflector Cup

- Reflects light emitted toward the rear of the LED.
- Directs more light toward the front.
- Improves light extraction efficiency.

6. Transparent Encapsulation (Epoxy Lens)

- Protects the semiconductor chip.
- Acts as a lens to focus and distribute light.
- Reduces internal reflection losses.
- Improves brightness and durability.

7. Semiconductor Substrate

- Supports the active layers.
- Provides mechanical strength.
- Helps in heat dissipation.

Types of LED Configurations

1. Homojunction LED

- Made from a single semiconductor material.
- Simple construction.
- Lower efficiency.
- Used in early LED designs.

2. Heterojunction LED

- Made from two different semiconductor materials.
- Better carrier confinement.
- Higher light output and improved efficiency.

3. Double Heterojunction LED

- Active region is sandwiched between two wider band-gap materials.
- Better confinement of electrons, holes, and photons.
- Reduced carrier recombination losses.
- Widely used in modern high-brightness LEDs.

4. Surface-Emitting LED

- Light is emitted perpendicular to the junction surface.
- Simple design.
- Commonly used in indicators and displays.

5. Edge-Emitting LED

- Light is emitted from the edge of the semiconductor chip.
- Higher directional output.
- Used in optical fiber communication.

Efficiency of LED

LED efficiency is the ability of an LED to convert electrical energy into visible or infrared light. It is the ratio of the optical output power to the electrical input power.

η = (Optical Output Power / Electrical Input Power) X 100%

Higher efficiency means more electrical energy is converted into useful light.

Types of LED Efficiency

1. Internal Quantum Efficiency

- Ratio of photons generated inside the LED to the number of injected electrons.
- Depends on recombination efficiency and material quality.

2. External Quantum Efficiency

- Ratio of photons emitted from the LED to the injected electrons.
- Includes internal generation and light extraction efficiency.

3. Power Efficiency

- Ratio of optical output power to electrical input power.
- Indicates overall energy conversion efficiency.

4. Luminous Efficiency

- Measures the amount of visible light produced per unit electrical power.
- Expressed in **lumens per watt (lm/W)**.

Factors Affecting LED Efficiency

1. Semiconductor Material: Direct band-gap materials provide higher efficiency.

2. Band-Gap Energy: Determines the wavelength and energy of emitted photons.

3. Current: Increasing current increases light output up to the rated limit. Excessive current reduces efficiency.

4. Temperature: Higher temperatures decrease brightness and efficiency.

5. Light Extraction: Internal reflection can trap photons inside the LED. Proper encapsulation and reflectors improve light extraction.

6. Crystal Defects: Defects increase non-radiative recombination and reduce light output.

7. Device Structure: Double heterojunctions and optimized chip designs significantly improve efficiency.

5.4 Light Output from LED and LED Structure

Light output from an LED is the visible or infrared light emitted when electrons and holes recombine in the active region of a forward-biased p–n junction. The light output of an LED is produced by the radiative recombination of electrons and holes. The amount of light emitted depends on the semiconductor material, forward current, device structure, and light extraction efficiency.

The **LED structure** refers to the physical construction and arrangement of the semiconductor layers, electrical contacts, reflector, substrate, and encapsulation that together enable efficient generation and emission of light.

Factors Affecting Light Output

Several factors influence the brightness and intensity of an LED.

1. Forward Current: Higher forward current increases light output up to the rated operating limit.

2. Semiconductor Material: Different semiconductor materials emit different wavelengths and brightness levels.

3. Band-Gap Energy: The band-gap energy determines the color and energy of the emitted light.

4. Temperature: As temperature increases:

- Light output decreases.
- Efficiency decreases.
- Device lifetime may be reduced.

5. Light Extraction Efficiency: Some photons remain trapped inside the semiconductor because of internal reflection. Proper LED design increases the amount of useful emitted light.

6. Crystal Quality: High-quality semiconductor crystals reduce defects and improve radiative recombination.

Methods to Increase Light Output

The light output of an LED can be improved by:

- Using direct band-gap semiconductor materials.
- Employing double heterojunction structures.
- Using transparent substrates.
- Applying anti-reflection coatings.
- Using reflector cups.
- Improving heat dissipation.
- Using dome-shaped epoxy lenses.
- Reducing internal optical losses.

LED Structure

A typical LED consists of the following components:

1. P-Type Semiconductor Layer

- Contains holes as majority carriers.
- Forms one side of the p–n junction.
- Connected to the positive terminal.

2. N-Type Semiconductor Layer

- Contains electrons as majority carriers.
- Forms the other side of the junction.
- Connected to the negative terminal.

3. Active Region

- Located near the p–n junction.
- Electron-hole recombination occurs here.
- Light is generated in this region.

4. Metal Contacts

Anode Contact

- Connected to the P-region.
- Supplies positive voltage.

Cathode Contact

- Connected to the N-region.
- Completes the electrical circuit.

5. Reflector Cup

- Positioned beneath the semiconductor chip.

- Reflects downward-emitted light toward the front.
- Improves light extraction efficiency.


6. Semiconductor Substrate

- Provides mechanical support.
- Helps dissipate heat.
- Supports the active layers.

7. Transparent Encapsulation (Epoxy Lens)

- Protects the LED chip.
- Increases light output.
- Acts as a focusing lens.
- Prevents damage from dust and moisture.

Simple Structure of an LED



5.5 Heterojunction LED

A Heterojunction LED is a Light Emitting Diode in which the p-type and n-type regions are made from two different semiconductor materials having different band-gap energies. The junction formed between these different semiconductor materials is called a heterojunction.

Heterojunction LEDs provide higher efficiency, greater brightness, and improved carrier confinement compared to ordinary homojunction LEDs.

Construction of a Heterojunction LED

A heterojunction LED consists of the following parts:

1. P-Type Semiconductor Layer

- Made from a wide band-gap semiconductor.
- Contains holes as majority charge carriers.
- Forms one side of the heterojunction.

2. Active Region

- Thin layer of narrow band-gap semiconductor.
- Region where electron-hole recombination occurs.
- Generates most of the emitted light.

3. N-Type Semiconductor Layer

- Made from a wide band-gap semiconductor.
- Contains electrons as majority charge carriers.
- Forms the other side of the heterojunction.


4. Metal Contacts

- Provide electrical connections.
- Allow current to flow through the LED.

5. Transparent Encapsulation

- Protects the semiconductor chip.
- Improves light extraction.
- Acts as a lens to increase brightness.

Simple Structure of a Heterojunction LED



Working Principle of a Heterojunction LED

A heterojunction LED operates on the **electroluminescent effect**. The operation of a heterojunction LED takes place in the following steps:

Step 1: Forward Bias

The positive terminal is connected to the P-region, and the negative terminal is connected to the N-region.

Step 2: Injection of Charge Carriers

Electrons move from the N-region toward the active region. Holes move from the P-region toward the active region.

Step 3: Carrier Confinement

Because the surrounding layers have a larger band-gap energy, electrons and holes remain confined within the narrow band-gap active region.

Step 4: Recombination

Electrons and holes recombine efficiently in the active region.

Step 5: Light Emission

The recombination releases energy as photons. The emitted light passes through the transparent encapsulation.

Advantages of Heterojunction LEDs

- Higher efficiency than homojunction LEDs.
- Greater brightness.
- Better carrier confinement.
- Lower power consumption.
- Reduced heat generation.
- Longer operating life.
- Faster response time.
- Higher reliability.

- Improved light extraction.
- Suitable for high-speed communication.

Limitations

- More complex manufacturing process.
- Higher production cost.
- Requires precise material growth techniques.
- Sensitive to fabrication defects.
- Advanced equipment is required for manufacturing.

Applications

- Optical fiber communication.
- High-brightness LED lighting and LED display boards.
- Traffic signals.
- Automotive lighting.
- Medical instruments.
- Infrared remote controls.
- Optical sensors.
- Laser diode technology.
- Consumer electronics.

5.6 Surface Emitting LED (SLED)


A Surface Emitting LED (SLED) is a type of LED in which light is emitted perpendicular (normal) to the surface of the PN junction. The light comes out through the top surface of the device. It is the simplest and most widely used LED in fiber optic communication systems for short-distance and low-speed communication. Surface-emitting LEDs produce a wider beam of light compared to edge-emitting LEDs.

Construction

A Surface Emitting LED consists of:

• P-type and N-type semiconductor layer
• Active region (PN junction) where light is generated
• Metal contacts (Anode and Cathode)
• Reflector to direct more light toward the emitting surface
• Transparent epoxy lens or window for efficient light emission

Simple Structure:-



Working Principle:-

The Surface Emitting LED works on the principle of electroluminescence.
Step 1: Forward Bias
The LED is connected in forward bias.
Step 2: Carrier Injection
Electrons from the N-region and holes from the P-region move towards the active region.
Step 3: Recombination
Electrons and holes recombine in the active region.
Step 4: Light Emission
The recombination releases energy in the form of photons (light). The photons are emitted through the top surface of the LED.

Advantages:-

- Simple and compact structure.
- Low cost.
- Easy fabrication.
- Low power consumption.
- High reliability.
- Long operating life.
- Suitable for short-distance optical communication.

Disadvantages:-

- Lower optical output power.
- Wide beam causes lower coupling efficiency with optical fibers.
- Lower modulation speed than Edge Emitting LED.
- Not suitable for long-distance communication.

Applications:-

- Fiber optic communication (short-distance links)
- Local Area Networks (LAN)
- Indicator lamps
- Display systems
- Optical sensors
- Consumer electronic devices

5.7 Device Performance Characteristics of LED:-

The device performance characteristics of an LED describe how efficiently and effectively the LED operates as an optical source. These characteristics determine its suitability for applications such as fiber optic communication, where reliable light transmission is required.

1. Optical Output Power:-

Optical output power is the amount of light emitted by the LED. It increases with the forward current up to a certain limit. Higher optical output power improves signal transmission through the optical fiber.

2. Spectral Width:-

Spectral width is the range of wavelengths emitted by the LED. LEDs emit light over a broad range of wavelengths (typically 30–100 nm). A wider spectral width causes chromatic dispersion in optical fibers, limiting long-distance communication.

3. Modulation Bandwidth (Response Speed):-

Modulation bandwidth is the maximum speed at which the LED can switch ON and OFF. LEDs have a moderate modulation speed, generally suitable for low- and medium-speed communication.

It is lower than that of laser diodes.

4. Efficiency:-

LED efficiency is the ability to convert electrical energy into light energy. It depends on:

- Internal and external quantum efficiency
- Semiconductor material and device structure
- Temperature

5. Forward Voltage:-

LEDs require a small forward voltage (typically 1.5–3.5 V, depending on the material and color). When forward biased, current flows and light is emitted.

6. Operating Temperature:-

The performance of an LED decreases as temperature increases. High temperatures reduce optical output power and efficiency. Proper cooling improves reliability and lifespan.

7. Reliability and Lifetime:-

LEDs are highly reliable devices. They have a long operating life, often exceeding 50,000 hours under normal operating conditions. They require very little maintenance.

8. Coupling Efficiency:-

Coupling efficiency is the percentage of emitted light that enters the optical fiber. It depends on the LED structure, lens design, and alignment with the fiber. Higher coupling efficiency improves communication performance.

5.8 Frequency Response and Modulation Bandwidth of LED:-

In fiber optic communication, the transmitted information is carried by modulating the light output of the LED. The performance of an LED depends on how quickly it can respond to changes in the input electrical signal. This is described by its frequency response and modulation bandwidth.

Frequency response is the ability of an LED to follow changes in the input electrical signal at different frequencies. It indicates how accurately the LED converts an electrical signal into a light signal as the signal frequency increases. At low frequencies, the LED follows the input signal accurately. As the frequency increases, the LED cannot respond instantly due to the finite recombination time of electrons and holes. Therefore, the light output gradually decreases at higher frequencies.

Factors Affecting Frequency Response:-

The frequency response of an LED depends on:

- Carrier recombination lifetime: Shorter lifetime gives a faster response.
- Junction capacitance: Higher capacitance slows down the LED.
- Semiconductor material: Better materials improve response speed.
- Device structure: Double heterojunction LEDs have better frequency response than homojunction LEDs.

Modulation Bandwidth:-

Modulation bandwidth is the maximum frequency up to which an LED can be modulated while maintaining effective light output. It determines the maximum data transmission rate of the LED. An LED with a higher modulation bandwidth can transmit data at higher speeds.

Factors Affecting Modulation Bandwidth:-

- Carrier recombination lifetime
- Junction capacitance
- Device configuration
- Operating current
- Temperature
- Reducing recombination time and capacitance increases the modulation bandwidth.

Relationship between Frequency Response and Modulation Bandwidth:-

Wider modulation bandwidth means better frequency response and higher data transmission capability. Typical Values of LED modulation bandwidth is approximately 10 MHz to 200 MHz. Laser diodes have much higher bandwidths, making them suitable for very high-speed communication.

Chapter 6: Laser Diode

6.1 Junction Laser Operating Principles (Brief and Extensive Explanation)


A junction laser or laser diode is a semiconductor device that converts electrical energy directly into coherent light through the process of stimulated emission. It is one of the most important light sources used in optical fiber communication, barcode scanners, laser printers, CD/DVD/Blu-ray players, medical equipment, and industrial applications.

A laser diode is usually made from direct band-gap semiconductor materials such as Gallium Arsenide (GaAs), Indium Phosphide (InP), or their alloys.

Operating Principle of a Junction Laser

A junction laser works on the principle of **stimulated emission** of radiation in a forward-biased p-n junction. When sufficient current is passed through the junction, electrons and holes recombine in the active region and emit photons. If the current exceeds a certain value called the **threshold current**, stimulated emission dominates, producing intense, coherent, monochromatic, and directional laser light.

Construction of a Junction Laser



A junction laser consists of:

1. **P-type semiconductor layer**
2. **N-type semiconductor layer**
3. **Active region** (junction where recombination occurs)
4. **Reflecting end faces (mirrors)** forming an optical resonator (Fabry–Perot cavity)
5. **Metal contacts** for electrical connections

The cleaved surfaces of the semiconductor crystal act as mirrors:

- One mirror is **100% reflecting**.
- The other is **partially reflecting** so that laser light can emerge.

Working of a Junction Laser

Step 1: Forward Biasing

The p-n junction is heavily forward biased.

- Electrons from the n-region move toward the p-region.
- Holes from the p-region move toward the n-region.
- Both accumulate in the thin active region.

Step 2: Carrier Injection

Large numbers of electrons and holes are injected into the active region. Because of heavy injection, carrier concentration becomes extremely high.

Step 3: Population Inversion

Normally, lower energy level contains more electrons. After heavy injection, upper energy level contains more electrons than the lower level. This condition is called **population inversion**. Population inversion is essential for laser action.

Step 4: Spontaneous Emission

Initially, electrons recombine with holes naturally. Each recombination releases one photon. These photons:

- Have random direction
- Random phase
- Random polarization

This is called **spontaneous emission**.

Step 5: Stimulated Emission

Some photons travel parallel to the junction. These photons strike excited electrons. Each photon stimulates another excited electron to emit a second photon.

The new photon has:

- Same frequency
- Same wavelength
- Same phase
- Same direction

This process is called **stimulated emission**.

Step 6: Optical Amplification

The mirrors at both ends reflect photons back and forth. As photons repeatedly pass through the active region, more stimulated emissions occur. Light intensity increases rapidly. This process is called **optical amplification**.

Step 7: Laser Output

When the optical gain exceeds the losses, Laser oscillation begins. The partially reflecting mirror allows some light to escape. The output is a highly intense laser beam.

Threshold Current

The minimum forward current required to start laser action is called the **threshold current**.

- Below threshold current → LED-like spontaneous emission.
- Above threshold current → Laser action due to stimulated emission.

Energy Band Diagram Explanation

During forward bias:

1. Electrons are injected into the conduction band.
2. Holes are injected into the valence band.

3. Electrons recombine with holes.
4. Energy difference between conduction band and valence band is released as photons.

Photon energy is:

$E = hv = hc/\lambda$

where:

- E = Photon energy
- h = Planck's constant
- v = Frequency
- c = Speed of light
- λ = Wavelength

Conditions Required for Laser Action

1. Forward-biased p-n junction
2. Direct band-gap semiconductor
3. Population inversion
4. Optical resonator (mirrors)
5. Stimulated emission
6. Current greater than threshold current

Characteristics of Laser Diode

- High efficiency
- Small size
- Low operating voltage
- Low power consumption
- High modulation speed
- Narrow spectral width
- Coherent light output
- Monochromatic light
- Highly directional beam

Advantages

1. Compact and lightweight
2. High efficiency
3. Low power consumption
4. Fast switching speed
5. Long operational life
6. Easy modulation
7. Low manufacturing cost
8. Suitable for optical fiber communication

Disadvantages

1. Temperature sensitive
2. Requires precise current control
3. Shorter lifetime than some gas lasers
4. Output power is comparatively lower
5. Beam divergence is higher than some other laser types

Applications

- Optical fiber communication
- CD/DVD/Blu-ray drives
- Barcode scanners
- Laser printers
- Medical surgery
- Laser pointers
- Industrial cutting and welding
- Distance measurement
- Optical sensors
- Military range finders

6.2 Threshold Current (Laser Diode)

Threshold current ((I_{th}) is the minimum forward current required for a laser diode to start producing laser light by stimulated emission. It is measured in milliamperes (mA). Below this current, the device behaves like an LED and emits only weak, incoherent light due to spontaneous emission. When the forward current reaches or exceeds the threshold current, the optical gain becomes equal to or greater than the internal losses, and laser action begins.

Importance of Threshold Current

- It determines the minimum operating current of a laser diode.
- A lower threshold current means:
    - Lower power consumption
    - Higher efficiency
    - Less heat generation
    - Longer device life
- A higher threshold current increases power consumption and reduces efficiency.
- It depends on semiconductor material, temperature, active region thickness, cavity length, and mirror reflectivity.

Graph of Output Power vs. Forward Current

- **Below threshold current ($I < I_{th}$)** Output power increases slowly due to spontaneous emission.
- **At threshold current ($I = I_{th}$)**: Laser action begins.
- **Above threshold current ($I > I_{th}$)**: Output power increases rapidly because of stimulated emission.

6.3 Heterojunction Lasers

A heterojunction laser is a type of semiconductor laser in which the p-type and n-type regions are made of two different semiconductor materials having different band-gap energies. The junction formed between these different materials is called a heterojunction.
A common example is Gallium Arsenide (GaAs) and Aluminium Gallium Arsenide (AlGaAs).


Construction of a Heterojunction Laser

A heterojunction laser consists of:

1. **P-type AlGaAs (cladding layer)**

2. **Thin GaAs active layer**
3. **N-type AlGaAs (cladding layer)**
4. **Metal contacts**
5. **Reflecting end faces (mirrors)** that form an optical cavity

The thin **GaAs active region** is sandwiched between two **AlGaAs cladding layers**. This structure is called a **double heterojunction (DH) laser**.



Working Principle

A heterojunction laser works on the principle of **stimulated emission**.

Step 1: Forward Biasing

The p-n junction is heavily forward biased, causing electrons and holes to be injected into the active region.

Step 2: Carrier Confinement

Because the active layer has a smaller band gap than the surrounding cladding layers, electrons and holes are confined to the thin active region. This increases the probability of recombination.

Step 3: Population Inversion

The high concentration of carriers in the active region creates **population inversion**, which is necessary for laser action.

Step 4: Stimulated Emission

When electrons recombine with holes, photons are emitted. These photons stimulate other excited electrons to emit identical photons with the same wavelength, phase, and direction.

Step 5: Optical Amplification

The mirrors at the ends of the laser reflect photons back and forth through the active region. This amplifies the light by repeated stimulated emission.

Step 6: Laser Output
When the optical gain exceeds the losses, a coherent laser beam emerges through the partially reflecting mirror.

Advantages of Heterojunction Lasers
- Low threshold current
- High efficiency
- Better carrier and optical confinement
- Low power consumption
- High output power
- High-speed operation
- Longer operating life
- Stable performance at higher temperatures

Disadvantages
- More complex fabrication
- Higher manufacturing cost
- Requires precise material growth and layer thickness control


Applications
- Optical fiber communication
- Laser printers
- CD/DVD/Blu-ray drives
- Barcode scanners
- Medical equipment
- Optical sensors
- Industrial measurement systems
- High-speed data communication

Difference Between Homojunction and Heterojunction Lasers

Homojunction Laser	**Heterojunction Laser**
Made from the same semiconductor material	Made from two different semiconductor materials
Higher threshold current	Lower threshold current
Lower efficiency	Higher efficiency
Poor carrier confinement	Excellent carrier confinement
Higher power loss	Lower power loss
Less commonly used	Widely used in modern laser diodes

6.4 Distributed Feedback (DFB) Lasers
A Distributed Feedback (DFB) laser is a type of semiconductor laser in which a **periodic grating (Bragg grating)** is built into the active region of the laser. Instead of using only the end mirrors for optical feedback, the grating provides distributed feedback along the entire length of the laser cavity.
DFB lasers produce single-wavelength, highly stable, and narrow-linewidth laser light, making them ideal for high-speed optical communication.

Construction of a DFB Laser



A DFB laser consists of:

1. **P-type semiconductor layer**
2. **Active region**
3. **N-type semiconductor layer**
4. **Periodic Bragg grating** along the active region
5. **Metal contacts**
6. **Laser output facet**

The **Bragg grating** is a series of closely spaced grooves or variations in the refractive index that reflect only a specific wavelength of light.

Working Principle

A DFB laser works on the principle of **stimulated emission** with **distributed optical feedback**.

Step 1: Forward Biasing

The p-n junction is heavily forward biased, injecting electrons and holes into the active region.

Step 2: Population Inversion

A large number of electrons and holes accumulate in the active region, creating **population inversion**.

Step 3: Stimulated Emission

Electrons recombine with holes and emit photons. These photons stimulate other excited electrons to emit identical photons with the same wavelength, phase, and direction.

Step 4: Distributed Feedback

The **Bragg grating** reflects only the desired wavelength while allowing other wavelengths to be suppressed. This distributed reflection occurs throughout the cavity, providing continuous optical feedback.

Step 5: Laser Output

When the optical gain exceeds the losses, the laser emits a **single-mode, coherent, monochromatic, and highly stable** laser beam.

Bragg Condition

The wavelength selected by the grating is given by the Bragg condition:

$\lambda_B = 2n \setminus \lambda$

where:

- λ_B = Bragg wavelength (laser wavelength)
- n = Effective refractive index
- λ = Grating period (spacing between grating lines)

Advantages

- Produces single-wavelength output
- Very narrow linewidth
- Excellent wavelength stability
- High-speed modulation capability
- Low signal distortion
- Suitable for long-distance communication
- Low chirping (small wavelength variation during modulation)

Disadvantages

- Complex fabrication
- Higher manufacturing cost
- Temperature-sensitive (often requires temperature control)
- Difficult to manufacture compared with ordinary laser diodes

Applications

- Optical fiber communication
- High-speed internet networks
- Wavelength Division Multiplexing (WDM) systems
- Fiber optic sensors
- Cable television (CATV)
- Medical instruments
- Spectroscopy
- Precision measurement systems

6.5 Cleaved Coupled Cavity (C^3) Laser

A Cleaved Coupled Cavity (C^3) Laser is a semiconductor laser in which two optical cavities are coupled together by a cleaved gap. The interaction between these cavities provides selective optical feedback, allowing the laser to emit a single wavelength with high stability and a narrow spectral linewidth. This design improves wavelength control compared with a conventional Fabry–Perot laser.


Construction

A Cleaved Coupled Cavity laser consists of:

1. **Active semiconductor region**
2. **Primary laser cavity**
3. **Secondary (coupled) cavity**
4. **Cleaved air gap** between the two cavities

5. **Reflecting end faces (mirrors)**
6. **Metal contacts** for forward biasing

The cleaved gap couples the two cavities optically and acts as a wavelength-selective feedback element.



Working Principle

The C^3 laser works on the principle of **stimulated emission** with **coupled-cavity optical feedback**.

Step 1: Forward Biasing

The p-n junction is heavily forward biased, injecting electrons and holes into the active region.

Step 2: Population Inversion

A high concentration of electrons and holes creates **population inversion**, which is necessary for laser action.

Step 3: Stimulated Emission

Electrons recombine with holes, emitting photons. These photons stimulate other excited electrons to emit identical photons with the same wavelength, phase, and direction.

Step 4: Coupled Cavity Feedback

The light travels between the two coupled cavities through the cleaved gap. Only specific resonant wavelengths receive strong feedback, while other wavelengths are suppressed.

Step 5: Laser Output

When the optical gain exceeds the cavity losses, the laser emits a **stable, coherent, monochromatic, and nearly single-mode** laser beam.

Advantages

- Better wavelength stability than Fabry–Perot lasers
- Narrow linewidth
- High spectral purity
- Improved single-mode operation
- Suitable for high-speed optical communication
- Reliable performance

Disadvantages

- Complex structure
- Difficult fabrication
- Higher manufacturing cost
- Requires precise alignment of the coupled cavities

Applications


- Optical fiber communication
- Long-distance telecommunication systems
- Wavelength Division Multiplexing (WDM)
- Optical sensing
- High-speed data transmission
- Scientific and laboratory instruments

6.6 Quantum Well Lasers

A Quantum Well Laser (QWL) is a semiconductor laser in which the active region is made extremely thin (typically 5–20 nm), forming one or more quantum wells. These quantum wells confine electrons and holes in a very small region, increasing the probability of recombination and improving laser performance.

Quantum well lasers have low threshold current, high efficiency, high output power, and high-speed operation, making them widely used in modern optical communication systems.

Construction



A quantum well laser consists of:

1. **P-type cladding layer**
2. **Barrier layer**
3. **Thin quantum well (active region)**
4. **Barrier layer**
5. **N-type cladding layer**

6. **Metal contacts**
7. **Reflecting end faces (optical cavity)**

The **quantum well** is a very thin semiconductor layer (such as **GaAs**) placed between higher band-gap materials (such as **AlGaAs**), which act as **barrier layers**.

Working Principle

A quantum well laser works on the principle of **stimulated emission**.

Step 1: Forward Biasing

The p-n junction is heavily forward biased, injecting electrons and holes into the active region.

Step 2: Carrier Confinement

The thin quantum well confines electrons and holes in a very small space due to quantum effects, increasing their concentration.

Step 3: Population Inversion

As carrier concentration increases, **population inversion** is achieved inside the quantum well.

Step 4: Stimulated Emission

Electrons recombine with holes and emit photons. These photons stimulate other excited electrons to emit identical photons with the same wavelength, phase, and direction.

Step 5: Optical Amplification

Photons are reflected between the mirrors, producing repeated stimulated emission and amplifying the light.

Step 6: Laser Output

When the optical gain exceeds the cavity losses, the laser emits a **coherent, monochromatic, and highly directional** beam.

Types of Quantum Well Lasers

1. **Single Quantum Well (SQW) Laser**
    - Contains one quantum well.
    - Simple structure and good performance.
2. **Multiple Quantum Well (MQW) Laser**
    - Contains several quantum wells separated by barrier layers.
    - Provides higher output power, better efficiency, and lower threshold current.
    - Most widely used in practical applications.

Advantages

- Low threshold current
- High efficiency
- High output power
- High-speed operation
- Low power consumption
- Better temperature stability
- Long operating life
- Compact size

Disadvantages

- Complex fabrication process
- Higher manufacturing cost

- Requires precise control of layer thickness
- Sensitive to fabrication defects

Applications

- Optical fiber communication
- High-speed internet networks
- Laser printers
- CD/DVD/Blu-ray drives
- Optical sensors
- Medical instruments
- Scientific research
- Fiber-optic communication systems

6.7 Modulation of Lasers – Rate Equations

Laser modulation is the process of varying the output intensity (power) of a laser according to an input electrical signal so that information (voice, data, or video) can be transmitted through an optical fiber. The behavior of a laser during modulation is described by rate equations, which explain how the number of charge carriers (electrons and holes) and photons changes with time.

Types of Laser Modulation

1. Direct Modulation

- The laser output is controlled by changing the injection current.
- Simple and inexpensive.
- Widely used in short- and medium-distance optical communication.

2. External Modulation

- The laser operates continuously, and an external optical modulator changes the light intensity.
- Used for high-speed and long-distance communication.
- Produces lower signal distortion.

Rate Equations

The operation of a laser diode is described by **two coupled rate equations**:

1. Carrier Rate Equation

$dN / dt = I / {}_qV - N / \tau_n - GS$

where:

- N = Carrier density
- I = Injection current
- q = Electronic charge
- V = Active region volume
- τ_n = Carrier lifetime
- G = Optical gain
- S = Photon density

Explanation:

- The first term represents carrier injection.
- The second term represents carrier loss due to spontaneous recombination.
- The third term represents carrier loss due to stimulated emission.

2. Photon Rate Equation

$$\frac{dS}{dt} = \Gamma G(N)S + \beta\frac{N}{\tau_n} - \frac{S}{\tau_p}$$

- S = **Photon density (photons/cm³)**
- N = **Carrier density (electrons/cm³)**
- Γ = **Optical confinement factor**
- $G(N)$ = **Material gain**
- β = **Spontaneous emission factor**
- τ_n = **Carrier lifetime**
- τ_p = **Photon lifetime in the cavity**

Explanation:

- The first term represents photon generation by stimulated emission.
- The second term represents photons produced by spontaneous emission.
- The third term represents photon loss from the laser cavity.

Advantages of Laser Modulation

- Enables transmission of digital and analog signals.
- Supports very high data rates.
- High bandwidth.
- Low signal loss.
- Suitable for long-distance optical communication.

6.8 Steady State Solution (Laser Diode)

The steady state solution of a laser diode is the operating condition in which the carrier density and photon density remain constant with time. In this condition, the rate of generation equals the rate of loss, so the laser operates with a constant output power.

Mathematically, at steady state:

$$\frac{dN}{dt} = 0 \quad \text{and} \quad \frac{dS}{dt} = 0$$

where:

- (N) = Carrier density
- (S) = Photon density

Explanation

When a laser diode is continuously forward biased:

1. Electrons and holes are injected into the active region.
2. They recombine to produce photons.
3. After a short time, the number of injected carriers becomes equal to the number of carriers lost by recombination.
4. Similarly, the number of photons generated becomes equal to the number of photons lost through the cavity.

5. As a result, the carrier density and photon density become constant. This condition is called the **steady state**.

Steady State Rate Equations: At steady state,

1. Carrier Rate Equation

dN / dt = 0

Therefore,

dN / dt= I / $_q$V - N / τ_n - GS

where:

- N = Carrier density
- I = Injection current
- q = Electronic charge
- V = Active region volume
- τ_n = Carrier lifetime
- G = Optical gain
- S = Photon density

  This equation shows that the injected carriers are balanced by carrier losses due to spontaneous and stimulated recombination.

2. Photon Rate Equation

dn / dt = 0 and dp / dt = 0

Therefore,

$$\frac{dS}{dt} = \Gamma G(N)S + \beta\frac{N}{\tau_n} - \frac{S}{\tau_p}$$

where:

- S = Photon density (photons/cm³)
- N = Carrier density (electrons/cm³)
- Γ = Optical confinement factor
- $G(N)$ = Material gain
- β = Spontaneous emission factor
- τ_n = Carrier lifetime
- τ_p = Photon lifetime in the cavity

This equation indicates that the photons generated inside the cavity are equal to the photons lost from the cavity.

Conditions for Steady State

- Continuous forward bias
- Constant injection current
- Population inversion is maintained
- Optical gain equals cavity losses
- Carrier density and photon density remain constant

Importance of Steady State Solution

- Ensures stable laser operation.
- Produces constant output power.
- Helps determine threshold current.
- Used in laser design and performance analysis.
- Essential for optical communication systems.

Advantages

- Stable laser output
- Constant optical power
- Improved communication performance
- Simplifies laser analysis and design

6.9 Transient Phenomena and Frequency Response (Laser Diode)

1. Transient Phenomena

Transient phenomena are the temporary changes in the output of a laser **diode** that occur immediately after the injection current is switched on or suddenly changed. During this period, the laser does not reach its stable output instantly. Instead, the carrier density and photon density vary with time until a steady state is achieved.

Causes of Transient Phenomena

- Sudden switching of injection current.
- Rapid changes in current during modulation.
- Carrier accumulation in the active region.
- Delay in photon generation.

2. Frequency Response

Frequency response is the ability of a laser diode to follow changes in the input modulation signal. It indicates how effectively the laser can transmit information at different modulation frequencies. At low modulation frequencies, the laser output follows the input signal accurately. As the modulation frequency increases, the laser cannot respond instantly because of finite carrier and photon lifetimes. Beyond a certain frequency, the output decreases significantly. This limiting frequency is called the **modulation bandwidth** or **3-dB bandwidth**.

Factors Affecting Frequency Response

1. Carrier lifetime and Photon lifetime
2. Threshold current and Injection current
3. Active region design
4. Temperature

Importance of Frequency Response

- Determines the maximum data transmission rate.
- Essential for high-speed optical communication.
- Helps in designing high-bandwidth laser systems.
- Improves communication efficiency.

Chapter 7: Optical Fiber

7.1 Introduction to Optical Fiber

An optical fiber is a thin, flexible, transparent strand made of glass (silica) or plastic that transmits information in the form of light signals. It works on the principle of **Total Internal Reflection (TIR)**, allowing light to travel through the fiber with very low loss.

Optical fibers are widely used in telecommunication, internet, cable television, medical instruments, and sensing applications because they can transmit data over long distances at very high speeds.


Principle of Optical Fiber

An optical fiber operates on the principle of Total Internal Reflection (TIR). Total Internal Reflection occurs when:

1. Light travels from a **denser medium** to a **rarer medium**.
2. The angle of incidence is **greater than the critical angle**.

Under these conditions, light is completely reflected back into the denser medium and continues to propagate through the fiber.

Construction of Optical Fiber



An optical fiber consists of three main parts:

1. Core: It is the central region through which light travels. It has a higher refractive index than the cladding.

2. Cladding: It surrounds the core which causes total internal reflection and prevents light from escaping. It has a lower refractive index than the core.

3. Protective Coating (Jacket): It covers the cladding and protects the fiber from moisture, dust, scratches, and mechanical damage.

Working of Optical Fiber

1. A light source (LED or laser diode) sends light into the fiber core.
2. The light strikes the core–cladding boundary.
3. Since the angle of incidence is greater than the critical angle, total internal reflection occurs.
4. The light reflects repeatedly along the length of the fiber.
5. The light reaches the receiving end with very little loss.

Thus, information is transmitted efficiently through the optical fiber.

Types of Optical Fiber

1. Single-Mode Fiber (SMF)

- Very small core diameter (about **8–10 µm**).
- Allows only one light path (mode).
- Suitable for long-distance communication.
- Has very low signal loss and high bandwidth.

2. Multi-Mode Fiber (MMF)

- Larger core diameter (about **50–100 µm**).
- Allows many light paths (modes).
- Used for short-distance communication.
- Lower bandwidth than single-mode fiber.

Characteristics of Optical Fiber

- High bandwidth
- Very low transmission loss
- Lightweight and flexible
- Immune to electromagnetic interference (EMI)
- High data transmission speed
- Secure communication
- Corrosion resistant
- Long operating life

Advantages

- High-speed data transmission
- Low signal attenuation
- Large bandwidth
- Small size, lightweight, reliable and durable
- Immune to electrical and magnetic interference
- Secure communication
- Long-distance transmission without significant loss

Disadvantages

- High installation cost
- Fragile compared to copper cables
- Difficult to splice and repair. It requires specialized equipment and skilled technicians

Applications

- Optical fiber communication
- Internet and broadband services
- Cable television (CATV)
- Telephone networks
- Medical endoscopy
- Industrial automation
- Military communication
- Optical sensors
- Computer networking

7.2 Structure of Optical Fiber

The structure of an optical fiber consists of three main parts: the core, cladding, and protective coating (jacket). These parts work together to transmit light efficiently through the principle of Total Internal Reflection (TIR).

An optical fiber has the following three layers:

1. Core

- The core is the central part of the optical fiber.
- It is made of high-quality glass (silica) or plastic.
- Light signals travel through the core.
- It has a higher refractive index than the cladding.

Functions:

- Carries the light signal.
- Provides the path for light transmission.

2. Cladding

- The cladding surrounds the core.
- It is also made of glass or plastic.
- It has a lower refractive index than the core.

Functions:


- Causes Total Internal Reflection (TIR).
- Prevents light from escaping from the core.
- Reduces transmission loss.

3. Protective Coating (Jacket or Buffer Coating)

- The outermost layer of the optical fiber.
- Made of **plastic or polymer material**.
- It does not transmit light.

Functions:

- Protects the fiber from moisture, dust, scratches, and mechanical damage.
- Increases the strength and durability of the fiber.



Working of the Structure

1. Light enters the core from a laser diode or LED.
2. Since the core has a higher refractive index than the cladding, the light undergoes Total Internal Reflection at the core–cladding interface.
3. The light reflects repeatedly inside the core and travels along the fiber with very little loss.
4. The protective coating shields the fiber from external damage without affecting light transmission.

Typical Dimensions

Part	**Typical Size**
Core	8–10 µm (Single-mode), 50–100 µm (Multimode)
Cladding	125 µm
Protective Coating	250–900 µm

Advantages

- Efficient light transmission
- Low signal attenuation
- High bandwidth
- Excellent protection against physical damage
- Long service life
- Reliable communication

Applications

- Optical fiber communication
- Internet and broadband services
- Cable television (CATV)
- Telephone networks
- Medical endoscopy
- Fiber-optic sensors
- Industrial automation
- Military communication

7.3 Propagation of Light Through an Optical Fiber and Numerical Aperture (NA)

An optical fiber works on the principle of Total Internal Reflection (TIR). The propagation of light in an optical fiber is the process by which light travels through the core by repeated Total Internal Reflection (TIR) at the core–cladding boundary.

Conditions for Total Internal Reflection

1. Light must travel from the **core (denser medium)** to the **cladding (rarer medium)**.
2. The angle of incidence at the core–cladding interface must be **greater than the critical angle**.

Working of Light Propagation

Step 1: Light Enters the Fiber

A light source such as a laser diode or LED sends light into the core of the optical fiber.

Step 2: Refraction at the Fiber End

The light bends (refracts) as it enters the core.

Step 3: Total Internal Reflection

When the light reaches the core–cladding boundary at an angle greater than the critical angle, it is completely reflected back into the core.

Step 4: Repeated Reflections

The light continues to undergo repeated total internal reflections and travels along the fiber with very little loss.

Step 5: Light Reaches the Output End

The light emerges from the other end of the fiber carrying the transmitted information.

Numerical Aperture (NA)

The Numerical Aperture (NA) is a measure of the light-gathering ability of an optical fiber. It indicates the maximum angle at which light can enter the fiber and still be guided through the core. NA means the fiber can accept light over a wider range of angles.

Formula for Numerical Aperture

$$NA = \frac{\sqrt{({n_1}^2 - {n_2}^2)}}{n_0}$$

Where n_0 = refractive index of external medium i.e. for air =1

Hence, NA $= \sqrt{({n_1}^2 - {n_2}^2)}$

where:

- n_1 = Refractive index of the core
- n_2 = Refractive index of the cladding

The numerical aperture is also related to the acceptance angle:

$NA = n_0 \sin\Theta$

where, θ = Acceptance angle (maximum angle at which light can enter the fiber)

Acceptance Angle

The acceptance angle is the maximum angle at which light can enter the fiber and still undergo total internal reflection inside the core.

$$\theta_a = \sin^{-1}\left(\frac{\sqrt{n_1^2 - n_2^2}}{n_0} \right)$$

- Larger acceptance angle → Larger NA
- Smaller acceptance angle → Smaller NA

Importance of Numerical Aperture

- Determines the light-collecting efficiency of the fiber.
- Affects the amount of optical power entering the fiber.
- Influences coupling efficiency between the light source and the fiber.
- Helps determine communication performance.

Advantages of High Numerical Aperture

- Easier light coupling.
- More light enters the fiber.

- Better signal transmission.
- Less alignment difficulty.

7.4 Pulse Broadening (Dispersion in Optical Fiber)

Pulse broadening is the spreading or widening of a light pulse as it travels through an optical fiber. Because of this spreading, adjacent pulses may overlap, causing signal distortion and limiting the data transmission rate. Pulse broadening is also known as **dispersion**.

Causes of Pulse Broadening

Pulse broadening occurs because different light rays or wavelengths travel through the fiber at different speeds or along different paths.

The main causes are:

1. Modal Dispersion (Intermodal Dispersion)

- Occurs mainly in **multimode fibers**.
- Different light rays (modes) travel along different paths.
- Some rays travel a longer path and arrive later than others.
- This causes the pulse to spread.

Characteristics:

- Present only in multimode fibers.
- Major cause of pulse broadening in multimode communication.
- Absent in single-mode fibers.

2. Material (Chromatic) Dispersion

- Caused by different wavelengths of light traveling at different speeds in the fiber material.
- Even a light source with a small wavelength range produces slight pulse spreading.

Characteristics:

- Occurs in both single-mode and multimode fibers.
- Depends on the properties of the fiber material.

3. Waveguide Dispersion

- Occurs because part of the light travels in the core and part travels in the cladding.
- Different portions of the light wave propagate at slightly different speeds.

Characteristics:

- Mainly observed in single-mode fibers.
- Depends on the fiber design and dimensions.

Effects of Pulse Broadening

- Signal distortion
- Overlapping of adjacent pulses (Inter-Symbol Interference)
- Reduced transmission distance
- Reduced bandwidth
- Lower data transmission rate
- Increased probability of communication errors

Methods to Reduce Pulse Broadening

1. Use **single-mode optical fibers**.
2. Use **laser diodes** instead of LEDs because they emit a narrower range of wavelengths.
3. Operate at wavelengths where material dispersion is minimum.

4. Use **dispersion-compensating fibers** or optical compensators.
5. Improve fiber design and manufacturing quality.

7.5 Advantages and Disadvantages of Fiber Optics

Fiber optics is a communication technology in which information is transmitted as light signals through thin strands of glass or plastic called optical fibers. It provides high-speed, long-distance, and reliable communication with very low signal loss.

Advantages of Fiber Optics

1. High Bandwidth
- Optical fibers can carry a very large amount of data.
- Suitable for high-speed internet and communication systems.

2. Low Transmission Loss
- Light signals experience very little attenuation.
- Information can travel over long distances without significant loss.

3. High-Speed Communication
- Data is transmitted at very high speeds.
- Supports modern broadband and telecommunication networks.

4. Immunity to Electromagnetic Interference (EMI)
- Optical fibers are not affected by electromagnetic or radio-frequency interference.
- Ensures clear and reliable communication.

5. Small Size and Lightweight
- Fiber optic cables are thinner and lighter than copper cables.
- Easy to transport and install.

6. Secure Communication
- Optical fibers are difficult to tap.
- Provides better security for data transmission.

7. Electrical Insulation
- Optical fibers do not conduct electricity.
- Safe to use in high-voltage and lightning-prone areas.

8. Corrosion Resistant
- Glass fibers are resistant to corrosion and many chemicals.
- Suitable for harsh environments.

9. Long-Distance Transmission
- Signals can travel long distances with fewer repeaters.
- Reduces maintenance costs.

10. High Reliability
- Long service life and stable performance.
- Suitable for continuous communication systems.

Disadvantages of Fiber Optics

1. High Initial Cost
- Installation and equipment costs are higher than copper cable systems.

2. Fragile
- Glass fibers can break if bent excessively or handled roughly.

3. Difficult Installation

- Requires careful handling and precise alignment during installation.

4. Complex Splicing

- Joining two optical fibers requires specialized tools and skilled technicians.

5. Expensive Equipment

- Optical transmitters, receivers, and testing equipment are costly.

6. Difficult Repair

- Fault detection and repair require specialized instruments and expertise.

7. Limited Power Transmission

- Optical fibers transmit light, not electrical power.
- Separate power cables are required for electrical devices.

Applications of Fiber Optics

- Optical fiber communication
- Internet and broadband services
- Telephone networks
- Cable television (CATV)
- Medical endoscopy
- Industrial automation
- Military communication
- Fiber-optic sensors
- Computer networking
- Undersea communication cables